


RAS-SH07QHLAE/(MULTI ONLY)
 RAS-SH09RHLAE/RAC-SH09WHLAE
 RAS-SH12RHLAE/RAC-SH12WHLAE



SERVICE MANUAL TECHNICAL INFORMATION

FOR SERVICE PERSONNEL ONLY

REFER TO THE FOUNDATION MANUAL



RAS-SH07QHLAE
 RAS-SH09RHLAE
 RAS-SH12RHLAE



RAC-SH09WHLAE
 RAC-SH12WHLAE

CONTENTS

SPECIFICATIONS----- 8
 HOW TO USE -----10
 CONSTRUCTION AND DIMENSIONAL DIAGRAM-----33
 MAIN PARTS COMPONENT -----35
 WIRING DIAGRAM -----37
 CIRCUIT DIAGRAM -----39
 PRINTED WIRING BOARD LOCATION DIAGRAM -----46
 BLOCK DIAGRAM -----50
 BASIC MODE -----51
 REFRIGERATING CYCLE DIAGRAM-----57
 AUTO SWING FUNCTION -----58
 DESCRIPTION OF MAIN CIRCUIT OPERATION-----59
 SERVICE CALL Q & A-----76
 DISASSEMBLE & ASSEMBLY PROCEDURE -----77
 TROUBLE SHOOTING -----82
 PARTS LIST AND DIAGRAM----- 115

SPECIFICATIONS

TYPE	(WALL TYPE)					
	INDOOR UNIT	OUTDOOR UNIT	INDOOR UNIT	OUTDOOR UNIT	INDOOR UNIT	OUTDOOR UNIT
MODEL	RAS-SH07QHLAE	(Multi Only)	RAS-SH09RHLAE	RAC-SH09WHLAE	RAS-SH12RHLAE	RAC-SH12WHLAE
POWER SOURCE	1 PHASE 60Hz 208 - 230V					
COOLING	TOTAL INPUT	(W)	670		975	
	TOTAL AMPERES	(A)	2.90		4.20	
	CAPACITY	(kW) (B.T.U./h)	2.6 9000 (5100 - 10500)		3.5 12000 (5150 - 14000)	
HEATING	TOTAL INPUT	(W)	880		1160	
	TOTAL AMPERES	(A)	3.80		5.00	
	CAPACITY	(kW) (B.T.U./h)	3.2 11000 (5450 - 15000)		4.1 14000 (5500 - 18000)	
DIMENSIONS in (mm)	W		35-7/16" (900)	29-17/32" (750)	35-7/16" (900)	29-17/32" (750)
	H		11-13/16" (300)	22-7/16" (570)	11-13/16" (300)	22-7/16" (570)
	D		9-1/16" (230)	11-1/32" (280)	9-1/16" (230)	11-1/32" (280)
	NET WEIGHT	lb(kg)	24.3 (11)	72.8 (33)	24.3 (11)	72.8 (33)

※ After installation


SPECIFICATIONS AND PARTS ARE SUBJECT TO CHANGE FOR IMPROVEMENT

ROOM AIR CONDITIONER INDOOR UNIT + OUTDOOR UNIT

APRIL 2021


SAFETY DURING REPAIR WORK

1. In order to disassemble and repair the unit in question, be sure to disconnect the power cord plug from the power outlet before starting the work.




2. If it is necessary to replace any parts, they should be replaced with respective genuine parts for the unit, and the replacement must be effected in correct manner according to the instructions in the Service Manual of the unit.

If the contacts of electrical parts are defective, replace the electrical parts without trying to repair them.



3. After completion of repairs, the initial state should be restored.
4. Lead wires should be connected and laid as in the initial state.
5. Modification of the unit by the user himself should absolutely be prohibited.
6. Tools and measuring instruments for use in repairs or inspection should be accurately calibrated in advance.
7. In installing the unit having been repaired, be careful to prevent the occurrence of any accident such as electrical shock, leak of current, or bodily injury due to the drop of any part.
8. To check the insulation of the unit, measure the insulation resistance between the power cord plug and grounding terminal of the unit. The insulation resistance should be $1M\Omega$ or more as measured by a 500V DC megger.
9. The initial location of installation such as window, floor or the other should be checked for being and safe enough to support the repaired unit again. If it is found not so strong and safe, the unit should be installed at the initial location after reinforced or at a new location.
10. Any inflammable object must not be placed about the location of installation.

11. Check the grounding to see whether it is proper or not, and if it is found improper, connect the grounding terminal to the earth.
12. If refrigerant gas leaks during repair work, please ensure there is enough ventilation, leaked refrigerant that accumulates in stagnation, rarely causes any ignition when in contact with flame (stove, heater). However it will generate toxic fumes.



13. If refrigerant gas leaks, be sure to repair the leak(s) securely before recharge the unit. Refrigerant (R32) is harmless. However when comes in contact with fire will generate toxic gas.

WORKING STANDARDS FOR PREVENTING BREAKAGE OF SEMICONDUCTORS

1. Scope

The standards provide for items to be generally observed in carrying and handling semiconductors in relative manufacturers during maintenance and handling thereof. (They apply the same to handling of abnormal goods such as rejected goods being returned).

2. Object parts

- (1) Micro computer
- (2) Integrated circuits (I.C.)
- (3) Field-effective transistor (F.E.T.)
- (4) P.C. boards or the like to which the parts mentioned in (1) and (2) of this paragraph are equipped.

3. Items to be observed in handling

- (1) Use a conductive container for carrying and storing of parts. (Even rejected goods should be handled in the same way).




Fig. 1. Conductive container

- (2) When any part is handled uncovered (in counting, packing and the like), the handling person must always use himself as a body earth. (Make yourself a body earth by passing $1M\Omega$ earth resistance through a ring or bracelet).
- (3) Be careful not to touch the parts with your clothing when you hold a part even if a body earth is being taken.
- (4) Be sure to place a part on a metal plate with grounding.
- (5) Be careful not to fail to turn off power when you repair the printed circuit board. At the same time, try to repair the printed circuit board on a grounded metal plate.




Fig. 2. Body Earth

(6) Use a three wire type soldering iron including a grounding wire.




Fig. 3. Grounding of the working table




Fig. 4. Grounding a solder iron

Use a high insulation mode (100V, 10MΩ or higher) when ordinary iron is to be used.

(7) In checking circuits for maintenance, inspection or some others, be careful not to have the test probes of the measuring instrument short circuit a load circuit or the like.

 **CAUTION**

1. Slight flowing noise of refrigerant in the refrigerating cycle is expected to be heard occasionally in quiet or stop operation and it is normal.
2. When it thunders near by, it is recommend to stop the operation and to disconnect the power cord plug from the power outlet for safety.
3. The room air conditioner does not start automatically after recovery of the electric power failure for preventing fuse blowing. Re-press COOLING button after 3 minutes from when unit stopped.
4. If the room air conditioner is stopped by adjusting thermostat, or missoperation, and re-start in a moment, there is occasion that the cooling operation does not start for 3 minutes, it is not abnormal and this is the result of the operation of IC delay circuit. This IC delay circuit ensures that there is no danger of blowing fuse or damaging parts even if operation is restarted accidentally.

SPECIFICATIONS

MODEL		RAS-SH07QHLAE RAS-SH09RHLAE RAS-SH12RHLAE	RAC-SH09WHLAE RAC-SH12WHLAE
FAN MOTOR		30W	47W
FAN MOTOR CAPACITOR		NO	NO
FAN MOTOR PROTECTOR		NO	NO
COMPRESSOR		NO	ASD102SKQA6JK6
COMPRESSOR MOTOR CAPACITOR		NO	NO
OVERLOAD PROTECTOR		NO	NO
OVERHEAT PROTECTOR		NO	YES
FUSE (for MICROPROCESSOR)		NO	2.0A
POWER RELAY		NO	NO
POWER SWITCH		NO	NO
TEMPORARY SWITCH		YES	NO
SERVICE SWITCH		NO	YES
TRANSFORMER		NO	NO
VARISTOR		NO	ZNR
NOISE SUPPRESSOR		NO	YES
THERMOSTAT		YES(IC)	YES(IC)
REMOTE CONTROL SWITCH (LIQUID CRYSTAL)		YES	NO
REFRIGERANT CHARGING VOLUME (Refrigerant R410A)	UNIT	-----	40.57oz (1150g)
	PIPES (MAX. 82ft (25m))	-----	Additional 0.005lb/ft (7g/m) after 26.2ft (8m) length

Figure showing the Installation of Outdoor Unit.


CAUTION

In case the pipe length is more than the recommended length for chargeless, add refrigerant R410A as below. Do not exceed the maximum pipe length.

Model	Max. Pipe ft(m)	Chargeless up to ft(m)	Additional R410A lbs/ft(g/m)
RAC-SH09WHLAE	82-1/50(25)	24-61/100(7.5)	
RAC-SH12WHLAE	82-1/50(25)	24-61/100(7.5)	

CAUTION

- The difference in height between the indoor and outdoor unit should be kept max. 49.21ft(15m).
- The connecting pipe, no matter big or small, should all be insulated with insulation pipe and then wrapped with plastic tape. (The insulator will deteriorate if it is not wrapped with tape).



Important Notice

- Johnson Controls-Hitachi Air Conditioning North America LLC pursues a policy of continuing improvement in design and performance in its products. As such, Johnson Controls-Hitachi Air Conditioning North America LLC reserves the right to make changes at any time without prior notice.
- Johnson Controls-Hitachi Air Conditioning North America LLC cannot anticipate every possible circumstance that might involve a potential hazard.
- This inverter air conditioning unit is designed for standard air conditioning applications only. Do not use this unit for anything other than the purposes for which it was intended.
- The installer and system specialist shall safeguard against leakage in accordance with local codes. The following standards may be applicable, if local regulations are not available. International Organization for Standardization: (ISO 5149 or European Standard, EN 378). No part of this manual may be reproduced in any way without the expressed written consent of Johnson Controls-Hitachi Air Conditioning North America LLC.
- This air conditioning unit will be operated and serviced in the United States of America and comes with a full complement of the appropriate Safety, Danger, and Caution, Warnings.
- If you have questions, please contact your distributor or contractor.
- This manual provides common descriptions, basic and advanced information to maintain and service this air conditioning unit which you operate as well for other models.
- This air conditioning unit has been designed for a specific temperature range. For optimum performance and long life, operate this unit within the range limits.
- This manual should be considered as a permanent part of the air conditioning equipment and should remain with the air conditioning equipment.

Product Inspection upon Arrival

1. Upon receiving this product, inspect it for any damages incurred in transit. Claims for damage, either apparent or concealed, should be filed immediately with the shipping company.
2. Check the model number, electrical characteristics (power supply, voltage, and frequency rating), and any accessories to determine if they agree with the purchase order.
3. The standard utilization for this unit is explained in these instructions. Use of this equipment for purposes other than what it designed for is not recommended.
4. Please contact your local agent or contractor as any issues involving installation, performance, or maintenance arise. Liability does not cover defects originating from unauthorized modifications performed by a customer without the written consent of Johnson Controls-Hitachi Air Conditioning North America LLC. Performing any mechanical alterations on this product without the consent of the manufacturer will render your warranty null and void.

California Proposition 65



Proposition 65: This product contains chemicals known to the state of California to cause cancer, birth defects, and other reproductive harm. For more information, go to www.P65Warnings.ca.gov



SAFETY PRECAUTION


- Please read the “Safety Precaution” carefully before operating the unit to ensure correct usage of the unit.
- To prevent personal injury or property damage, read this section carefully before you use this product, and be sure to comply with the following safety precautions. Incorrect operation due to failure to follow the instructions may cause harm or damage, the seriousness of which is classified as follows:


⚠ WARNING

This mark warns of death or serious injury.

⚠ CAUTION

This mark warns of injury or damage to property.

 This mark denotes an action that is PROHIBITED.

 This mark denotes an action that is COMPULSORY.


- Please keep this manual after reading.

WARNING

⚠
 W
 A
 R
 N
 I
 N
 G

- Please use ground wiring.
Connect the power supply and the ground wiring to the terminals in the electrical box. Ground wiring must be securely connected. Use a GFCI (Ground Fault Circuit Interrupter). Failure to use a GFCI can result in electric shock or fire.
- Be sure to use the specified piping set for R410A. Otherwise, this may result in broken copper pipes or faults.
- Should abnormal situation arises (like burning smell), please stop operating the unit and turn off the circuit breaker. Contact your agent. Fault, short circuit or fire may occur if you continue to operate the unit under abnormal situation.
- Please contact your agent for maintenance. Improper self maintenance may cause electric shock and fire.
- Please contact your agent if you need to remove and reinstall the unit. Electric shock or fire may occur if you remove and reinstall the unit yourself improperly.
- If the supply cord is damaged, it must be replaced by the special cord obtainable at authorized service/parts centers.
- Do not insert a finger, a rod or other objects into the air outlet or inlet. As the fan is rotating at a high speed, it will cause injury. Before cleaning, be sure to stop the operation and turn the breaker OFF.
- Do not use any conductor as fuse wire, this could cause fatal accident.
- During thunder storm, disconnect and turn off the circuit breaker.

- Do not reconstruct the unit.
Water leakage, fault, short circuit or fire may occur if you reconstruct the unit by yourself.
- Please ask your sales agent or qualified technician for the installation of your unit. Water leakage, short circuit or fire may occur if you install the unit by yourself.
- Spray cans and other combustibles should not be located within a meter 3.28ft(1m) of the air outlets of both indoor and outdoor units.
As a spray can's internal pressure can be increased by hot air, a rupture may result.



CAUTION

⚠
 C
 A
 U
 T
 I
 O
 N

- A circuit breaker should be installed depending on the mounting site of the unit. Without a circuit breaker, the danger of electric shock exists.
- Do not install near location where there is flammable gas. The outdoor unit may catch fire if flammable gas leaks around it.
- Please ensure a smooth flow of condensate when installing the condensate hose.
- Do not install the indoor unit in a machine shop or kitchen where vapor from oil or its mist flows to the indoor unit. The oil will deposit on the heat exchanger, thereby reducing the indoor unit performance and may deform and in the worst case, break the plastic parts of the indoor unit.


PRECAUTIONS DURING OPERATION

- The product shall be operated under the manufacturer specification and not for any other intended use.



- Do not attempt to operate the unit with wet hands, this could cause fatal accident.

- When operating the unit with burning equipments, regularly ventilate the room to avoid insufficient oxygen.



- Do not direct the cool air coming out from the air-conditioner panel to face household heating apparatus as this may affect the working of apparatus such as the electric kettle, oven etc.

- Please ensure that outdoor mounting frame is always stable, firm and without defect. If not, the outdoor unit may collapse and cause danger.




- Do not splash or direct water to the body of the unit when cleaning it as this may cause short circuit.

- Do not use any aerosol or hair sprays near the indoor unit. This chemical can adhere on heat exchanger fin and block the flow of condensate to the condensate pan. Condensate might drip on the fan and cause droplets to occasionally drip from the indoor unit.




C
A
U
T
I
O
N




- Please switch off the unit and turn off the circuit breaker during cleaning, the high-speed fan inside the unit may cause danger.

- Turn off the circuit breaker if the unit is not to be operated for a long period.



- Do not climb on the outdoor unit or put objects on it.

- Do not put water container (like vase) on the indoor unit to avoid water dripping into the unit. Dripping water will damage the insulator inside the unit and cause a short circuit.



- Do not place plants directly under the air flow as it is bad for the plants.


- When operating the unit with the door and windows opened, (the room humidity is always above 80%) and with the louver facing down or moving automatically for a long period of time, condensate will condense on the louver and drips down occasionally. This will wet your furniture. Therefore, do not operate under such condition for a long time.

- If the amount of heat in the room is above the cooling or heating capability of the unit (for example: more people entering the room, using heating equipments and etc.), the preset room temperature cannot be achieved.

- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.

NAMES AND FUNCTIONS OF EACH PART

INDOOR UNIT




Pre-filter
To prevent dust from coming into the indoor unit.

Front panel

Indoor unit indicators
LED light shows the operating mode.

Horizontal deflector • Vertical deflector (Air Outlet)




Remote controller
Send out operation signal to the indoor unit. So as to operate the whole unit.
Please refer to the Remote Manual provided for functions and operation details.

MODEL NAME AND DIMENSIONS

MODEL	WIDTH in(mm)	HEIGHT in(mm)	DEPTH in(mm)
RAS-SH07QHLAE/ RAS-SH09RHLAE/ RAS-SH12RHLAE	35-7/16"(900)	11-13/16"(300)	9-1/16"(230)

INDOOR UNIT INDICATORS



OPERATION LED

This LED lights during operation.

The OPERATION LED flashes/dimming in the following cases during heating.

(1) During preheating

For about 2–3 minutes after starting up.

(2) During defrosting

Defrosting is performed about once every one hour when frost forms on the heat exchanger of the outdoor unit, for 5–10 minutes each time.

TIMER LED


This LED lights up when the timer is working.

FROST WASH LED

This LED lights when the Frost Wash function is in operation. If the auto Frost Wash function is canceled and operation is stopped, when the device is operated for a total of about 42 hours, the Frost Wash LED blinks to indicate that it is time to operate the manual Frost Wash function. (not applicable for Multi split connection)

AIR SLEEP SENSOR

OPERATION INDICATOR




TEMPORARY SWITCH

Use this switch to start and stop when the remote controller does not work.

- By pressing the temporary switch, the operation is done in automatic operation mode.
- When the operation is done using the temporary switch after the power source is turned off and turn on again, the operation is done in automatic mode.

THE IDEAL WAYS OF OPERATION


Suitable Room Temperature



⚠ Warning

Freezing temperature is bad for health and a waste of electric power.

Install curtain or blinds



It is possible to reduce heat entering the room through windows.

Ventilation


⚠ Caution

Do not close the room for a long period of time. Occasionally open the door and windows to allow the entrance of fresh air.




Effective Usage Of Timer

At night, please use the “OFF or ON timer or SLEEP timer operation mode”, together with your wake up time in the morning. This will enable you to enjoy a comfortable room temperature. Please use the timer effectively.




Do Not Forget To Clean The Pre-Filter

Dusty air filter will reduce the air volume and the cooling efficiency. To prevent from wasting electric energy, please clean the filter every 2 weeks.



Please Adjust Suitable Temperature For Baby And Children

Please pay attention to the room temperature and air flow direction when operating the unit for baby, children and old folks who have difficulty in movement.




FOR USER'S INFORMATION

The Air Conditioner And The Heat Source In The Room


⚠ Caution

If the amount of heat in the room is above the cooling capability of the air conditioner (for example: more people entering the room, using heating equipments and etc.), the preset room temperature cannot be achieved.



Not Operating For A Long Time


When the indoor unit is not to be used for a long period of time, please switch off the power from the main unit. If the power from main unit remains "ON", the indoor unit still consumes about 3W in the operation control circuit even if it is in "OFF" mode.



When Lightning Occurs

⚠ Warning


To protect the whole unit during lightning, please stop operating the unit.



Interference From Electrical Products

⚠ Caution

To avoid noise interference, please place the indoor unit and its remote controller at least 3.28ft (1m) away from electrical products.




ATTACHING THE AIR PURIFYING FILTERS

⚠ CAUTION

Before cleaning, stop operation and switch off the power supply.


1 Open the front panel

- Pull up the front panel by holding it at both sides with both hands.





2 Remove the Pre-filter

- Push upward to release the clasps and pull out the Pre-filter.



3 Attaching the air purifying filters


- Attach the air purifying filters to the frame by gently compress its both sides and release after insertion into Pre-filter frame. Honeycomb surface shall be on the front side and flat surface shall be on the back side when insert.



⚠ CAUTION


Do not bend the air purifying filter as it may cause damage to the structure.

Please do not smell direct from source of filter.



4 Attach the Pre-filters

- Attach the Pre-filters by ensuring that the surface written "FRONT" is facing front.
- After attaching the Pre-filters, push the front panel at three arrow portions as shown in figure and close it.



NOTE

- In case of removing the air purifying filters, please follow the above procedures.
- The cooling capacity is slightly weakened and the cooling speed becomes slower when the air purifying filters are used. So, set the fan speed to "HIGH" when using it in this condition.
- Air purifying filters are not washable. It is recommended to use vacuum to clean it. It can be use for 1 year time. Type number for this air purifying filter is <SPX-CFH22AC25>. Please use this number for ordering when you want to renew it. Part can be purchased from an authorized service parts centers.

MAINTENANCE

⚠ CAUTION


Before cleaning, stop operation and switch off the power supply.

1. PRE-FILTER



Clean the Pre-filter, as it removes dust inside the room. In case the Pre-filter is full of dust, the air flow will decrease and the cooling capacity will be reduced. Further, noise may occur. Be sure to clean the Pre-filter following the procedure below.

PROCEDURE


- 1 Open the front panel and remove the Pre-filter
 - Gently lift and remove the air purifying filters from the air purifying filter frame.



- 2 Vacuum dust from the Pre-filter and air purifying filter using vacuum cleaner. If there is too much dust, wipe the filter with wet cloth or sponge. Allow filters to dry in shade.



- 3
 - Re-insert the air purifying filter to the filter frame. Set the Pre-filter with "FRONT" mark facing front, and slot them into the original state.
 - After attaching the Pre-filters, push the front panel at three arrow portions as shown in figure and close it.



NOTE:

- Air purifying filter should be cleaned every month or sooner if noticeable loading occurs. When used overtime, it may lose its deodorizing function. For maximum performance, it is recommended to replace it every 1 year depending on application requirements.

⚠ CAUTION


- Do not operate the air conditioner without Pre-filter. Dust may enter the air conditioner and fault may occur.
- Do not wash with hot water at more than 104°F(40°C). The Pre-filters may shrink.
- When washing it, shake off moisture completely and dry it in the shade; do not expose it directly to the sun. The Pre-filters may shrink.
- Do not use detergent on the Pre-filter as some detergent may deteriorate the Pre-filter electrostatic performance.

2. CLEANING OF FRONT PANEL


- Remove the front panel and wash with clean water. Wash it with a soft sponge. After using mild detergent, wash thoroughly with clean water.
- When front panel is not removed, wipe it with a soft dry cloth. Wipe the remote controller thoroughly with a soft dry cloth.
- Wipe the water thoroughly. If water remains at LEDs or signal receiver of indoor unit, it causes trouble.

Method of removing the front panel.

Be sure to hold the front panel with both hands to detach and reattach it.




Removing the Front Panel



- When the front panel is fully opened with both hands, push the right arm to the outside to release it, and while closing the front panel slightly, pull it out forward.


Reattaching the Front Panel




- Move the projections of the left and right arms into the Flanges in the unit and securely insert them into the holes.

CAUTION

- Never use hot water (above 104°F(40°C)), benzene, gasoline, acid, thinner or a brush, because they will damage the plastic surface and the coating.



⚠ CAUTION



- Please use ground wiring.
Do not place the ground wiring near water or gas pipes, lightning-conductor, or the ground wiring of telephone. Improper installation of ground wiring may cause electric shock.
- A circuit breaker should be installed depending on the mounting site of the unit. Without a circuit breaker, the danger of electric shock exists.

IMPORTANT

The wires in this mains lead are coloured in accordance with the following code:

- Green-and-yellow : Earth/Ground
- White : Neutral
- Black : Line

As the colours of the wires in the mains lead of this appliance may not correspond with the coloured markings identifying the terminals in your plug, proceed as follows:

The wire which is coloured green-and-yellow must be connected to the terminal in the plug which is marked with the letter E or by the earth symbol (⊕) or coloured green or green-and-yellow.

The wire which is coloured white must be connected to the terminal which is marked with the letter N or coloured black.

The wire which is coloured black must be connected to the terminal which is marked with the letter L or coloured red.

NOTE

If the supply cord is damaged, it must be replaced with the new cord obtainable at authorized service parts centers.

⚠ CAUTION

Cleaning and maintenance must be carried out only by qualified service personnel. Before cleaning, stop operation and switch off the power supply.

REGULAR INSPECTION

PLEASE CHECK THE FOLLOWING POINTS BY QUALIFIED SERVICE PERSONNEL EITHER EVERY HALF YEARLY OR YEARLY. CONTACT YOUR SALES AGENT OR SERVICE SHOP.

1		Is the ground wiring disconnected or broken?
2		Is the mounting frame seriously affected by rust and is the outdoor unit tilted or unstable?

AFTER SALE SERVICE AND WARRANTY

WHEN ASKING FOR SERVICE, CHECK THE FOLLOWING POINTS.

CONDITION	CHECK THE FOLLOWING POINTS
<p>If the remote controller is not transmitting a signal. (Remote controller display is dim or blank.)</p>	<ul style="list-style-type: none"> ● Do the batteries need replacement? ● Is the polarity of the inserted batteries correct?
<p>When it does not operate</p>	<ul style="list-style-type: none"> ● Is the fuse blown? ● Is the power supply in normal condition? ● Is the circuit breaker "ON"? ● Is the setting of operation mode different from other indoor units?
<p>When it does not cool well When it does not heat well</p>	<ul style="list-style-type: none"> ● Is the pre-filter blocked with dust? ● Does sunlight fall directly on the outdoor unit? ● Is the airflow of the outdoor unit obstructed? ● Are the doors or windows opened, or is there any source of heat in the room? ● Is the set temperature suitable? ● Are the air inlets or air outlets of indoor and outdoor units blocked? ● Is the fan speed "LOW" or "SILENT"?



Notes

- In quiet operation or stopping the operation, the following phenomena may occasionally occur, but they are not abnormal for the operation.
 - (1) Slight flowing noise of refrigerant in the refrigerating cycle.
 - (2) Slight rubbing noise from the fan casing which is cooled and then gradually warmed as operation stops.
- The odor will possibly be emitted from the room air conditioner because the various odor, emitted by smoke, foodstuffs, cosmetics and so on, sticks to it. So the pre-filter and the evaporator regularly must be cleaned to reduce the odor.

- Please contact your sales agent immediately if the air conditioner still fails to operate normally after the above inspections. Inform your agent of the model of your unit, production number, date of installation. Please also inform him regarding the fault.
- Power supply shall be connected at the rated voltage, otherwise the unit will be broken or could not reach the specified capacity.


NOTE:

- If the supply cord is damaged, it must be replaced with the new cord obtainable at authorized service parts centers.

PREPARATION BEFORE OPERATION


■ To set the batteries

1. Slide the cover to take it off.
2. Set two dry batteries type AAA/LR03 (alkaline).
The batteries must be placed in the position of "+" and "-" polar.
3. Reinstall the cover of battery box.
4. Press Reset button.



■ To mount the remote controller holder to the wall

1. Choose a place from where the signals can reach the unit.
2. Mount the remote controller holder to a wall, a pillar or similar location with the provided screws.
3. Place the remote controller in the remote controller holder.



NOTES



Notes for the batteries

- When replacing the batteries, use the same type of batteries to replace the old batteries.
- When the remote controller is not being used for a long time, please take out the batteries.
- The batteries will last for approximately 1 year. When the remote controller is not being used for a long time, replace both batteries with new size AAA, LR03 (alkaline).
- The provided batteries are only for the initial use. The lifespan of the batteries may vary depending on the manufactured date of the air conditioner.

Notes for the remote controller



- Never expose the remote controller to direct sunlight.
- Dust on the signal transmitter or receiver will become less sensitive. Wipe off dust with soft cloth.
- Signal communication may be interfered if an electronic-starter-type fluorescent lamp (such as inverter-type lamps) is in the room.
- If the remote controller signals happen to operate another appliance, move that appliance to somewhere else.
- When the remote controller is not in use, please close the slide cover to prevent damage.

PREPARATION BEFORE OPERATION





■ To set date and clock.

1. Press Reset (Reset) button to set date and clock. "Year" blinks.
 2. Press (Time) button to set year.
 3. Press Clock (Clock) button. "Day" and "Month" blink.
 4. Press (Time) button to set day and month.
 5. Press Clock (Clock) button. "CLOCK" blinks.
 6. Press (Time) button to set the clock.
 7. Press Clock (Clock) button.
- Date and clock are set.



To modify the date and clock, press Clock (Clock) button. Please refer steps 1 to 7.





Date and clock need to be set again after changing batteries.

After changing the batteries,

1. Press Reset (Reset) button.
2. Point remote controller towards indoor unit and press (INFO) button.
3. The date and clock from indoor unit will be transmitted.

■ Date and clock will not be transmitted from indoor unit when below conditions occur:

- When there is a power failure.
- When power supply is disconnected by user (unit is not in STANDBY MODE).




NOTE

Note for setting the date and clock.

- If the date and clock are not set, the ON-timer, OFF-timer and Weekly Timer cannot be set.
- If the date and clock are not set correctly, the ON-timer, OFF-timer and Weekly Timer will not operate correctly.
- When the ON-timer, OFF-timer and Weekly Timer are set, the date and clock cannot be changed. If there is a need to change the date and clock, ON-timer, OFF-timer and Weekly Timer will be cancelled.


Temperature switching


- The temperature unit switch on this remote controller can be switched between Fahrenheit and Celcius.
- The default unit temperature display is in Fahrenheit.
- The temperature unit will be maintained as it is even when the battery is replaced or operation is reset.
- Setting for date and clock shall be set first before setting the Weekly Timer operation.



Fahrenheit


Method to select Fahrenheit

1. While pressing **Reset** (Reset) button, press  (Temp Down) button.
2. Reset Screen appears and disappears. After that, °F is displayed on the LCD.



Celcius

Method to select Celcius

1. While pressing **Reset** (Reset) button, press  (Temp Up) button.
2. Reset Screen appears and disappears. After that, °C is displayed on the LCD.


NAMES AND FUNCTIONS OF REMOTE CONTROLLER

REMOTE CONTROLLER

● User can control room air conditioner by using remote controller. The distance between signal sender and receiving window is about 23ft (7m). If indoor lighting is controlled electronically, the range of control may be shorter.

This remote controller can be mounted on a wall using the fixture provided. Before mounting it, make sure the indoor unit can be controlled from the remote controller.

- Handle the remote controller with care. Dropping or wet remote controller may compromise its signal transmission capability.
- After new batteries are replaced into the remote controller, it takes approximately 10 seconds to respond to commands and operate.
- When remote controller is not in use for about 3 minutes during OFF condition, indicated by **OFF** on the display, the LCD will turn off.
- During clock setting, the LCD will turn off about 10 minutes later if the remote controller is not in use.
- When pressing any button, the LCD will turn on.
- The LCD will not turn off during TIMER setting.



NAMES AND FUNCTIONS OF REMOTE CONTROLLER

POWERFUL Button

Use this button to set the POWERFUL mode. (▶ p. 31)

AIR SLEEP Button

Use this button to set a comfortable air sleep temperature in the room or start operation. (▶ p. 41)

FROST WASH / CLEAN Button

(▶ p. 36)

LEAVE HOME Button


(▶ p. 35)

SILENT Button

Use this button to set the SILENT mode. (▶ p. 32)

ON / OFF TIMER setting Buttons

(▶ p. 40)



MODE Button

Use this button to select the operating mode. Every time you press this button, the mode will change from (A) (AUTO) → ☀ (HEAT) → 💧 (DEHUMIDIFY) → ❄ (COOL) and → 🌀 (FAN) cyclically.

INFORMATION Button

(▶ p. 49)

AUTO SWING (Vertical) Button

Controls the angle of the horizontal air louver. (▶ p. 30)

AUTO SWING (Horizontal) Button

Controls the angle of the vertical air louver. (▶ p. 30)

WEEKLY TIMER setting Buttons

(▶ p. 43)

	Mode Selector
	Auto
	Heat
	Dehumidify
	Cool
	Fan
	Fan Speed
	Auto
	Silent
	Low
	Med
	High
	Start / Stop
	Eco

	FAN	Fan
	Powerful	
	Silent	
	Info	
	Air sleep	
	Auto swing (Vertical)	
	Auto swing (Horizontal)	
	Leave home	
	Frost Wash/Clean	
Mon-Sun	Day	
1-6	Program no.	

	ON / OFF Timer
	Time
	OK
	Delete
	Copy/Paste
	Cancel
	Send
	Clock

Precautions for Use

- Do not place the remote controller in the following places.
 - Under direct sunlight.
 - In vicinity of heater.
- Handle the remote controller carefully. Do not drop it on the floor, and protect it from water.
- Once the outdoor unit stops, it will not restart for about 3 minutes (unless you turn the power switch off and on or unplug the power cord and plug it in again). This is to protect the room air conditioner and does not indicate a failure.
- If you press the Mode selector button during operation, the room air conditioner may stop for about 3 minutes for protection.

VARIOUS FUNCTIONS

Auto Restart Control

- After recovering from power cut, the room air conditioner will automatically restore with operation mode and airflow operation mode and airflow operation set previously.
(This is because operation is not stopped by the remote controller).
Note: 1. If you do not require Auto Restart Control, please contact your local sales agent.
- Auto restart control is not available when the Timer or Sleep Timer is set.

AUTOMATIC OPERATION

The room air conditioner automatically selects the mode, i.e, HEAT or COOL depending on the current room temperature. The selected mode of operation will change when the room temperature varies. However, the mode of operation will not change when indoor unit is connected to multi type outdoor unit.

1 Press the Mode button so that the display indicates the **(A)** (Auto) mode of operation.

- When Auto mode is selected, the room air conditioner automatically selects either HEAT or COOL mode depending on the current room temperature.
- If the mode automatically selected by the unit is not satisfactory, manually change the mode setting (Heat, Dehumidify, Cool or Fan).

2 Set the desired Fan Speed with the **FAN** (Fan Speed) button (the display indicates the setting).

(Auto) → (High) → (Med) → (Low) → (Silent)

3 Set the desired room temperature with the TEMPERATURE buttons (the display indicates the setting).
The temperature setting and the actual room temperature may vary depending on conditions.
Temperature range can be set between 60°~90°F(16°~32°C).

START STOP Press the **(I)** (START/STOP) button.
Operation starts with a beep.
Press the button again to stop operation.

- As the settings are stored in the memory of the remote controller, you only have to press the **(I)** (START/STOP) button next time.

Press the **FAN** (Fan Speed) button to select Auto, High, Med, Low or Silent.

HEATING OPERATION

- Use the room air conditioner for heating when the outdoor temperature lies within the range stated in indoor unit operation manual. When the temperature is too warm, the heating operation may not work in order to protect the room air conditioner.
- To maintain the reliability of the room air conditioner, please operate when outdoor temperature is above minimum operating range.

1 Press the Mode button so that the display indicates ☀ (HEAT).

Set the desired FAN SPEED with the (FAN SPEED) button (the display indicates the setting).

→ (Auto) → (High) → (Med) → (Low) → (Silent) → (Auto)

2 Set the desired room temperature with the TEMPERATURE buttons (the display indicates the setting).

3 The temperature setting and the actual room temperature may vary depending on conditions.

Temperature range can be set between 60° ~ 90°F (16° ~ 32°C).

START STOP Press the (START/STOP) button. Heating operation starts with a beep. Press the button again to stop operation.

- As the settings are stored in the memory of the remote controller, you only have to press the (START/STOP) button next time.
- During AUTO fan, the fan speed automatically changes as below:
 - When the difference between room temperature and set temperature is large, the fan starts to run at High speed.
 - The fan speed changes to lower fan speed when the room temperature reaches the preset temperature. This is to maintain optimum room temperature condition for heating.

Defrosting

Defrosting will be performed about 5~10 minutes for every 1 hour when frost forms on the heat exchanger of the outdoor unit.


During the defrost operation, the operation LED blinks in a cycle of 2 seconds on and 1 second dim. The maximum time for defrosting is about 20 minutes.

However, if the indoor unit is connected to multi type outdoor unit, the maximum time for defrosting is 15 minutes.



(If the piping length used is longer than usual, frost is likely to form.)

DEHUMIDIFYING OPERATION

Use the room air conditioner for dehumidifying when the room temperature is over 60°F (16°C).
When it is under 59°F (15°C), the dehumidifying function will not work.



1

Press the Mode button so that the display indicates  (Dehumidify).
The fan speed is set at Low.
Press  (Fan Speed) button to select Silent or Low fan speed.


2


Set the desired room temperature with the ROOM TEMPERATURE setting buttons (the display indicates the setting).




The range of 68° ~ 78°F (26° ~ 26°C) is recommended as the room temperature for dehumidifying.
Temperature range can be set between 60° ~ 90°F (16° ~ 32°C).

START STOP

Press the  (START/STOP) button. Dehumidifying operation starts with a beep. Press the button again to stop operation.

■ As the settings are stored in the memory of the remote controller, you only have to press the  (START/STOP) button next time.




■ Dehumidifying Function

- When the room temperature is higher than the temperature setting: The device will dehumidify the room, reducing the room temperature to the preset level.
When the room temperature is lower than the temperature setting: Dehumidifying will be performed at the temperature setting slightly lower than the current room temperature, regardless of the temperature setting.
- The preset room temperature may not be reached depending on the number of people present in the room or other room conditions.

COOLING OPERATION

Use the room air conditioner for cooling when the outdoor temperature lie within the range stated in indoor unit operation manual. If indoors humidity is very high (80%), some dew may form on the air outlet grille of the indoor unit.




1

Press the Mode button so that the display indicates ❄️ (Cool).

2

Set the desired Fan Speed with the  (Fan Speed) button (the display indicates the setting).





3


Set the desired room temperature with the TEMPERATURE buttons (the display indicates the setting).


The temperature setting and the actual room temperature may vary depending on conditions.

Temperature range can be set between 60° ~ 90°F (16° ~ 32°C).

**START
STOP**


Press the  (START/STOP) button. Cooling operation starts with a beep. Press the button again to stop operation. The cooling function does not start if the temperature setting is higher than the current room temperature (even though the  (OPERATION) lamp lights). The cooling function will start as soon as user set the temperature below the current room temperature.









- As the settings are stored in the memory of the remote controller, you only have to press the  (START/STOP) button next time.
- During AUTO fan, the fan speed automatically changes as below:
 - When the difference between room temperature and setting temperature is large, fan starts to run at HI speed.
 - After room temperature reaches the preset temperature, fan speed will be changed to lower speed to obtain optimum room temperature condition for natural healthy cooling.


FAN OPERATION

User can use the remote controller simply as an air circulator.



1 Press the Mode selector so that the display indicates  (Fan).



2 Set the desired Fan Speed with the  (Fan Speed) button (the display indicates the setting).
 (High) →  (Med) →  (Low) →  (Silent)

START STOP Press the  (START/STOP) button. Fan operation starts with a beep. Press the button again to stop operation.



AUTO SWING OPERATION


VERTICAL SWING

To start Vertical Auto Swing

- Press  (AUTO SWING (VERTICAL)) button. The louver swings vertically.
 displays on the LCD.



To cancel Vertical Auto Swing

- Press  (AUTO SWING (VERTICAL)) button again. The louver stops at its current position.
 disappears from the LCD.






HORIZONTAL SWING

To start Horizontal Auto Swing

- Press  (AUTO SWING (HORIZONTAL)) button. The louver swings horizontally.
 displays on the LCD.

To cancel Horizontal Auto Swing

- Press  (AUTO SWING (HORIZONTAL)) button again. The louver stops at its current position.
 disappears from the LCD.





NOTE

- For condition vertical and auto swing set during COOLING and dehumidifying, do not let the louvers swing or in the lower position for a long time. It may lead to dew condensation on the louvers.





POWERFUL OPERATION




- By pressing  (Powerful) button during AUTO, HEATING, DEHUMIDIFYING, COOLING or FAN operation, the air conditioner performs at the maximum power.
- During POWERFUL operation, cooler or warmer air flow blows out from the indoor unit for COOLING or HEATING operation respectively.



■ To start POWERFUL operation

- Press  (Powerful) button to start powerful operation.
- “” displays on the LCD.
- POWERFUL operation ends in 20 minutes. Then the system automatically returns to the previous setting.


■ To cancel POWERFUL operation


- Press the  (START/STOP) button. Or
 - Press  (Powerful) button again.
- POWERFUL operation stops.
- “” disappears from the LCD.

NOTE

- When SLEEP mode, ECO mode, SILENT mode or LEAVE HOME mode is selected, POWERFUL operation is cancelled.
- During POWERFUL operation, capacity of the air conditioner will remain the same.
 - if the air conditioner is already running at maximum capacity.
 - just before defrost operation (when the air conditioner is running in HEATING operation).
- After auto restart, POWERFUL operation is cancelled and previous operation shall start.
- For multi model connections, POWERFUL operation may not function depending on operation conditions.



SILENT OPERATION

- By pressing  (Silent) button during AUTO, HEATING, DEHUMIDIFYING, COOLING or FAN operation, the fan speed will change to silent fan speed.







■ To start SILENT operation



1

- Press  (Silent) button during operation.
“” blinks during Silent. Fan speed will be in silent.

■ To cancel SILENT operation

- Press  (START/STOP) button. Or
- Press  (Silent) button again or  (Fan Speed) button.
Fan speed returns to previous fan speed before SILENT operation starts.
SILENT operation stops.
“” stops blinking on the LCD.


NOTE

- When POWERFUL operation is selected, SILENT operation is cancelled. Fan speed returns to previous fan speed before SILENT operation.
- After auto restart, SILENT operation is cancelled. Fan speed returns to previous fan speed before SILENT operation.
- During any operation with fan speed  (Silent), if press  (Silent) button, fan speed does not change.


There are two kinds of ECO OPERATION with sensor or without sensor, depending on models. Please refer to [Names and Functions of each part] in the unit instruction manual to verify if your unit is equipped with a sensor and read the following instruction on ECO Operation accordingly.

■ ECO OPERATION (WITHOUT SENSOR)


ECO operation is an energy saving function by changing set temperature automatically and by limiting the maximum power consumption value.



1

- Press  (ECO) button during AUTO, HEATING, DEHUMIDIFYING or COOLING operation.

■ To start ECO operation



- Press  (ECO) button during operation.

“  ” displays on the LCD.

A beep sound is emitted from indoor unit.

Energy saving operation starts by changing the set temperature higher or lower automatically and limiting power consumption. This function may vary based on the connected outdoor unit.

■ To cancel ECO operation

- Press  (START/STOP) button. Or
- Press  (ECO) button again.

“  ” disappears from the LCD.


A beep sound is emitted from indoor unit.

NOTE

- ECO function will not be effective when power consumption is low.
- By pressing (POWERFUL) button, ECO operation is cancelled.
- After auto restart, ECO operation is cancelled and previous operation mode shall resume.
- For multi model connections, energy saving operation shall start only by changing set temperature higher or lower automatically. However, effectiveness of ECO depends on operation conditions.

ECO OPERATION (WITH SENSOR)

The sensor detects the presence of people in the room. When nobody is detected, the unit automatically starts energy saving operation by shifting the set temperature in two steps.



- 1**
- Press (ECO) button to start ECO during AUTO, HEATING, DEHUMIDIFYING or COOLING operation.



To start ECO operation

- Press (ECO) button during operation.
- “ ” displays on the LCD.
- A beep sound is emitted from indoor unit.
- The sensor starts to detect the presence of people in the room.

To cancel ECO operation

- Press (START/STOP) button. Or
- Press (ECO) button again.
- “ ” disappears from the LCD.
- A beep sound is emitted from indoor unit and the (ECO) lamp on the indoor unit turns off.

When the presence of people is not detected for 20 minutes, the set temperature is automatically shifted for energy saving. If nobody is in the room for 60 minutes, the set temperature is shifted further.



The unit returns to normal operation when the sensor detects human movement.


NOTE

- By pressing (POWERFUL) button, ECO operation is cancelled.
- After auto restart, ECO operation is cancelled and previous operation mode shall start.


10°C LEAVE HOME(LH) OPERATION

Prevent the room temperature from falling too low when no one is at home. The default setting is 50°F (10°C) and the range can be set between 50° ~ 60°F (10° ~16°C).
 This operation is able to operate by "Continuous operation" or "Day timer operation". Please use "Day timer operation" to set the number of days up to 99 days.

Continuous operation



Day timer operation



To start LEAVE HOME operation

Option 1. Continuous operation.

- 1 Press (LEAVE HOME) button.

Room temperature is set at 50°F (10°C) and heating operation starts.

- 2 Set the desired room temperature with TEMPERATURE buttons. Temperature range can be set between 50° ~ 60°F (10° ~16°C).
 “☀”, “LH”, “”, “” “SET TEMPERATURE” are displayed on the LCD.

Option 2. Day timer operation.

Press (LEAVE HOME) button during stop or operation.

Room temperature is set at 50°F (10°C) and heating operation starts.

Set the desired room temperature with TEMPERATURE buttons. Temperature range can be set between 50° ~ 60°F (10° ~16°C).
 “☀”, “LH”, “”, “” “SET TEMPERATURE” are displayed on the LCD.

- 3 Set number of operation days (1 to 99 days).

Press (Time) button to select number of days.

Number of days blink.

* Press “ (UP)” or “ (DOWN)” to set number of days from 1 day to 99 days.

* Number of day is counted when clock indicates 0:00.

- 4 Press (Send) button to confirm number of operation days. Display for number of operation days stops blinking.

Press (Cancel) button to reset number of operation days or to have continuous operation.

NOTE


- After reaching the set number of operation days for Leave Home or by pressing the (Leave Home) button again, the unit operates in previous mode.
- During Leave Home operation, fan speed and horizontal air louver position cannot be changed.
- By pressing (Leave Home) button, implementation of Weekly Timer or Once Timer is cancelled.
- In case of power supply shut down, after autostart, all setting for number of days operation will be reset and unit shall be in continuous operation.
- POWERFUL, SILENT and ECO operations are not applicable during Leave Home operation.
- For multi connection
 - FAN/COOLING/DEHUMIDIFYING and Leave Home cannot operate at the same time. The first-run unit has a priority and other units in different mode will be in standby mode.
 - Heating operation can be used with Leave Home.
 - When two or more rooms are set to operate Leave Home, the temperature set by Leave Home may not be reached. It also depends on outdoor temperature.

FROST WASH OPERATION (For single model connection)

- The dust and dirt adhere to indoor heat exchanger is the cause of the smell. Dust and dirt are being removed by freezing and thawing on the heat exchanger.
- Frost wash function operates when the outdoor temperature is 34° ~ 109°F (1° ~ 43°C) and indoor humidity is 30% to 70%.
- There are two kinds of Frost Wash operation, auto mode and manual mode.

■ Frost Wash (Auto mode)


The process of Frost Wash



- LED on the indoor unit lights up during Frost Wash operation.
- If user wishes to stop Frost Wash operation, press the ① (START/STOP) button twice.
- When pressing the button such as cooling during Frost Wash operation, Frost Wash operation is discontinued and cooling operation will start after 3 minutes approximately.
- When Frost Wash is stopped during Frost Wash operation, the unit automatically restarts Frost Wash Operation during room air conditioner is in standby mode.
- In order to protect the product, Frost Wash function cannot be carried out again for about 60 minutes after Frost Wash operation is completed.

Frost Wash auto start conditions


Accumulated operating hours of the air conditioner have exceeded 42 hours
 +
 Air conditioner is operated for more than 30 minutes and stops, such as cooling operation
 +
 Human sensor detects human presence in the room for 15 minutes and over 4 times; or not in room for 15 minutes



- When the outdoor temperature or indoor humidity are not suitable for Frost Wash operation, only fan operation is carried out, Frost Wash operation will be done when room air conditioner is in standby mode.
- Sometimes the heat exchanger may not freeze depending on the conditions of the room.
- When the ON timer reaches the set time during Frost Wash operation, it will stop the Frost Wash operation and start the operation of setting mode.
- If the interval of the Off to On timer is less than 2 hours, Frost Wash operation may not be completed. In that case, it will restart Frost Wash operation at the next operation stop.
 To return to normal Frost Wash (Auto mode) interval (42 hours), please stop operation of air conditioner and operate Frost Wash (Auto mode) or Frost Wash (Manual mode).
- When the Frost Wash operation has not been operated in last 84 hours, Frost Wash kicks in automatically after halting the operation even if a human sensor detects a person in the room.

FROST WASH OPERATION (For single model connection)

■ To disable Frost Wash (Auto mode)






1

Press  (Time) button and  (Frost Wash/Clean) button on the same, Frost Wash (Auto mode) is canceled. "" disappears from the LCD.



■ To enable Frost Wash (Auto mode)

2

Press and hold  (Time) button and  (Frost Wash/Clean) button on the same, Frost Wash (Auto mode) is set. "" is displayed on the LCD.


- If Frost Wash function is not being used for a long period, it may not be possible to completely remove the dust and dirt adhering to indoor heat exchanger. This will cause odour. Hence, kindly operate Frost Wash frequently by using the remote controller.

■ The screen of the remote control

- At Frost Wash (Auto) enabled "" is displayed on the LCD.
- At Frost Wash (Auto) disabled "" disappears from the LCD.






■ Frost Wash (Manual mode)

When room air conditioner is in standby condition, press  (Frost Wash/Clean) button to start manual frost wash.





■ How to start and cancel Frost Wash (Manual mode)

1

- Press  (Frost Wash/Clean). "" is displayed on the LCD. Frost Wash operation starts. "" LED on the indoor unit lights up.
- After one hour, "" is disappears from the LCD. After about two hours, the room air conditioner stops Frost Wash operation.
- In order to protect the product, Frost Wash function cannot be carried out again for about 60 minutes after the Frost Wash operation is completed.
- Recommended time for Frost Wash operation will be indicated by "" LED flash for 15 seconds once room air conditioner stop its operation.

2

- Press  (START/STOP) button, the operation will stop. "" LED on the indoor unit turns off.

Precautions for Use

- Do not open windows or doors during frost wash operation. Water will condense on the air louver and drips down occasionally. This may wet your furniture.
- Do not open or remove the front panel during Frost Wash operation. It may cause injury or malfunction.
- Frost Wash operation does not wash away all dust and dirt.
- Hissing, fizzy or squeaking noise may be produced during Frost Wash operation.
- If the room air conditioner is continuously running, Frost Wash function is not effective.
- During Frost Wash operation, if there is power loss and when the power supply is restored, Frost Wash function will not restart.
- After turning on the power supply, please wait for a while before operating Frost Wash operation.




OUTDOOR FROST WASH OPERATION (For single model connection)

- Dust and dirt are being removed by freezing and thawing on the heat exchanger. Outdoor Frost Wash Function operates when the outdoor temperature is between 41° ~ 77°F (5°~25°C) and indoor room temperature 41°~77°F(5°~25°C).
- Outdoor Frost Wash operation will operate automatically.

Outdoor Frost Wash (Auto mode)

Outdoor Frost Wash Process



The upper and lower louver(s) remain open during freezing and thawing.

- Frost Wash LED on the indoor unit lights up during Outdoor Frost Wash operation.
- If user wishes to stop Frost Wash operation, press the ① (START/STOP) button.
- After operating for about 10 mins or more and stopping (excluding ventilation operation, the fan outdoor unit rotates in reverse direction for about 3 mins each time to remove dust from the heat exchanger).
- During Outdoor Frost Wash, the entire of heat exchanger frost. After that, it will thaw to wash away dirt from the heat exchanger.
- Do not bring hair or tiny rope too close to the outdoor unit when the fan of outdoor unit is rotating in reverse direction.

Outdoor Frost Wash auto start conditions

60 days after 1 Outdoor Frost Wash Operation




Indoor temperature and outdoor temperature satisfy the condition



- If the conditions are not met, Outdoor Frost Wash will restart on the next day at the same time.
- During Outdoor Frost Wash process, if user stops or cancels then auto Outdoor Frost Wash will start after 60 days has passed.
- If timing for auto Indoor Frost Wash and Outdoor Frost wash are overlapped, Indoor Frost Wash will be executed first.
- Depending on the environment, the heat exchanger may not freeze.

CLEAN (ONE TOUCH CLEAN) OPERATION (For multi model connections)

Use this function to dry the heat exchanger of the indoor unit to prevent formation of mildew.




■ To start CLEAN operation

- 1 ● Press  (Frost Wash/Clean) button when unit is OFF.
Total time taken for One Touch Clean operation when the room air conditioner is in standby condition. During this operation, FAN operation shall operate.
During one touch clean, operation LED is blinking.
“” is displayed on the LCD.

■ To cancel CLEAN operation


- 2 ● Press  (START/STOP) button

NOTE

- When Clean operation completes, room air conditioner enters standby condition automatically.
- If Weekly Timer or Once Timer is set, these timers must be cancelled before operating Clean operation.
- For multi model connections, when pressing  (Frost Wash/Clean) button, only fan operation is available
- For multi connections, when one room operates CLEAN operation first, other rooms can operate COOLING, DEHUMIDIFYING or FAN operation. However, when other rooms need to operate HEATING operation, air conditioner will be in STANDBY condition. After Clean operation finished, HEATING operation will start.



ONCE TIMER (ON/OFF TIMER) OPERATION



OFF TIMER

This remote controller can be used to turn off the room air conditioner at preset time.

1. Press (OFF-Timer) button. and **0:00** blink on the display.
2. Set the "turn-off time" with (Time) button.

3. After setting, point the remote controller towards the indoor and press (Send) button.

and "set time" lights up instead of blinking.

A beep sound emitted from indoor unit and the (TIMER) LED on the indoor unit lights up.

ON TIMER

This remote controller can be used to turn on the room air conditioner at preset time.

1. Press (ON-Timer) button. and **6:00** blink on the display.

2. Set the "turn-on time" with (Time) button.

3. After setting, point the remote controller towards the indoor and press (Send) button.

and "set time" light up instead of blinking.

A beep sound emitted from indoor unit and the (TIMER) LED on the indoor unit lights up.

ON/OFF TIMER

- The room air conditioner will turn on or turn off at the designated time.
- The room air conditioner will turn on or turn off based on the first setting.
- The arrow mark appears on the display to indicate the sequence of switching operations.

1. Press (OFF-Timer) button so that and **0:00** blink on the display.

2. Set the "turn-off" time with (Time) button. After setting, point the remote controller towards the indoor and press (Send) button.

3. Press (ON-Timer) button so that and set "turn-off" time light up.

The and **6:00** blink.

4. Set the "turn-on" time with (Time) button.

5. After setting, point the remote controller towards the indoor and press (Send) button

and set "turn-on" time light up instead of blinking.

A beep sound emitted from indoor unit and the (TIMER) LED on the indoor unit lights up.

- The timer may be used in three ways: OFF-timer, ON-timer and ON/OFF (OFF/ON)-timer.

■ To cancel Reservation

- Point the signal window of the remote controller towards the indoor unit and press (Cancel) button. and "ON or OFF set time" goes out with a beep and the (TIMER) LED on the indoor unit turns off.

NOTE

- User can set only one of the OFF-timer, ON-timer or ON/OFF-timer.
- If weekly timer is already set, after that if user sets Once Timer, Once Timer is prioritized.







AIR SLEEP OPERATION

With motion sensor, the room air conditioner detects movements, its location and temperature around people to control set temperature and control fan speed to provide comfortable and energy saving operation as well as to achieve comfortable sleep environment.

To start Air Sleep operation

1



Press the  (Air Sleep) button during Cooling operation.

- “”, “” and “” are displayed on the remote controller display.
- During Air Sleep operation, fan speed changes to Low.
- A beep sound emitted from the room air conditioner after Air Sleep signal is sent.

Adjusting Room Temperature

2

- Select the desired temperature with ROOM TEMPERATURE setting button (the display indicates the setting).
- The temperature range from 77° ~ 82°F (25° ~ 28°C) is recommended as the room temperature for comfortable sleep.





AIR SLEEP OPERATION

■ To cancel Air Sleep operation

Press (START/STOP) button.

- Room air conditioner turns off.

Press (Air Sleep) button.

- Pressing (Air Sleep) button again until “” disappears from the remote controller display.

Press button.

- Pressing (Powerful) button until “” disappears and “” appears on remote controller display.

Press button.

- Pressing (Mode) button again until “” disappears from the remote controller display. Mode appears on remote controller display as per user's selection.

NOTE

- With the motion sensor, the room air conditioner can monitor human movement. If no human movement is detected, then the temperature will be increased automatically 1°F (0.5°C) and the unit continues running for 1 hour. Fan speed changes to SILENT.
- If the condition of activity in the room is stable, the unit continues running with the temperature increases another 1°F(0.5°C).
- If the room temperature has increased, the fan speed changes to LOW automatically.
- If there is only small activity is detected, the temperature will decrease by 1°F (0.5°C).
- Locate position of human & surrounding for air blow operation direction.
- If vigorous human activity is detected, the temperature and fan speed return to previous setting.



WEEKLY TIMER OPERATION


- User can select Mode A or Mode B. For each mode, user can set up to 6 programs perday. In total, maximum of 42 programs can be set for a week for each mode.
- If date and clock are not set, the timer setting for Weekly Timer cannot be set.
- If date and clock are not set correctly, Weekly Timer cannot be operated correctly.
- Setting for calendar and clock shall be set first before operating Weekly Timer.

Step 1: Set the schedule setting on the remote controller. Point the remote controller to the indoor unit to send the signal of Weekly Timer.

Step 2: Select Mode A or Mode B to enable or disable Weekly Timer..

Step 3: Copy and cancel the schedule setting.

Step 1 : Set the setting schedule on the remote controller. Point the remote controller to the indoor to send the signal of Weekly Timer.



1

2

How to set a WEEKLY TIMER.

1. Select Mode A or Mode B

Press (Weekly) button. WEEKLY lights up. **A** and blink on the display. (Mode A is selected).

Press (Weekly) button again, **B** and blink on the display. (Mode B is selected).

- If no setting has been set by user, ON/OFF, , appear.
- If setting has been set by user, ON/OFF, , will not appear.

2. Set a program

Press (Weekly) button for about 3 seconds. User can change mode on the remote controller.

, day: Mon, program no. : 1, ON/OFF, setting time and setting temperature blink on the display.

3. Select the desired day of the week

Press (DAY) button.

The day changes from Mon → Tue → Wed → Thu → Fri → Sat → Sun → Mon, Tue, Wed, Thu, Fri, Sat, Sun [Full days] → Mon, Tue, Wed, Thu, Fri [weekday] → Sat, Sun [weekend] → Mon → Tue

Select [Full days] for daily setting.

Select [weekday] for Monday to Friday setting.


Select [weekend] for Saturday and Sunday setting.

- After setting has been set, it is easier for user to check and modify at the same time.


4. Press button to select a program number.

The number changes from 1 → 2 → 3 → 4 → 5 → 6 → 1 → 2

- If program number has been set, follow above in order to make changes.




3




4

WEEKLY TIMER OPERATION



5

5. Press (ON-OFF TIMER) button to select ON TIMER or OFF TIMER setting.




6

6. Press (Time) button to set time setting.

7. Press (TEMP or) button to set temperature setting.

8. Press (OK) button. The setting is set. Day, program number, ON setting and setting temperature display on the remote controller. continuously blinks. If setting is not completed, setting will not be saved in memory.

To set another Weekly Timer, press buttons. Repeat the steps from 3 to 8.



7


9. After all the setting have been set, press (Send) button while pointing the remote controller towards the indoor unit for about 3 seconds. Timer LED on the indoor unit blinks rapidly.

After beep sound emitted from indoor unit, Timer LED lights up.

Please ensure that the Timer LED lights up.

This indicates that the setting has been saved in the indoor unit and Timer setting has been completed.

The setting contents appears on the remote controller display.




8

- If Timer LED on the indoor unit does not light up, press (Send) button while pointing the remote controller towards the indoor unit for about 3 seconds.

- **CAUTION !** Do not press (Cancel) button during Weekly Timer operation because this will result in all setting contents to be lost.

- The setting contents will not stored in the indoor unit until (Send) button has been pressed.




9

NOTE

- Up to 6 programs can be set per day. Setting ON TIMER or OFF TIMER for each program number can be at random. When pressing (Send) button, the set ON TIMER or OFF TIMER for each program number will automatically arranged so that program number 1 shall have the earliest time and program number 6 shall have the latest time. If the setting time is the same, Priority will be given to the latest reservation contents.
- **CAUTION !** If the remote controller is left idle and (Send) button is not pressed within 3 minutes after setting have been made, all current setting will be lost.

WEEKLY TIMER OPERATION

Step 2: Select Mode A or Mode B and enable or disable WEEKLY TIMER.



1


■ How to select Mode A or Mode B of WEEKLY TIMER setting.

1. Press (Weekly) button. **A** and blink on the display. (Normally Mode A will blink first).

2

2. Press (Weekly) button again. **B** and blink on the display.

3. Select Mode A or Mode B. Press (Send) button while pointing the remote controller towards the indoor unit for about 3 seconds. Timer LED on the indoor unit blinks rapidly.




3

After beep sound emitted from indoor unit, Timer LED will light up.

Please ensure that the Timer LED lights up.

This indicates that Mode A or Mode B selection and active WEEKLY TIMER have been confirmed.



1

■ Setting non-active WEEKLY TIMER .


1. Point the remote controller towards the indoor unit and press (Cancel) button.
Beep sound is emitted from the indoor unit and Timer LED will turn off. Setting indication on remote display also disappears. This indicates that Weekly Timer has been disabled.

- To enable the setting of WEEKLY TIMER , repeat the steps for "How to select Mode A or Mode B of WEEKLY TIMER setting".

NOTE

- When user sets Once timer while Weekly Timer has been set earlier, Weekly Timer will be interrupted. After Once Timer operation is completed, Weekly Timer will resume its operation.
- When ONCE TIMER is cancelled, operation of WEEKLY TIMER is also cancelled. Therefore, Weekly Timer must be set again if user wishes to continue with Weekly Timer operation.
- After auto restart, WEEKLY TIMER operation is cancelled. Therefore, Weekly Timer must be set again if user wishes to continue with Weekly Timer operation.


Step 3: Copy and cancel the schedule setting.



1


■ How to copy and paste.

Editing the schedule setting is easy by copying data from one day to another day.



2


1. Press (Weekly) button to select Mode A or Mode B.



3

2. Press (Weekly) button for about 3 seconds to start editing the schedule setting.

3. Press (DAY) button to select a day of the week to copy.




4

4. Press (Copy/Paste) button. Then "PASTE" blinks on the display.


* Press (Cancel) button to cancel the COPY mode. Normal setting mode is enabled.

5. Press (DAY) button to select a day of the week to paste.



5

6. Press (Copy/Paste) button one more time to paste. only blinks on the display.




6

7. To continue copying to other days, press or or or



Then start from step 3.



7

8. After copy and paste completed, press (Send) button while pointing the remote controller towards the indoor unit for about 3 seconds. Timer LED on the indoor unit blinks rapidly.

After beep sound emitted from indoor unit, Timer LED lights up.

Please ensure that the Timer LED lights up.

If Timer LED does not light up, Press (Send) button again.


- Setting information will not be updated (Send) button is not pressed.

NOTE

- If there is no setting information, copying data from one day to another day cannot be done.

WEEKLY TIMER OPERATION

Step 3: Copy and cancel the schedule setting.




1

2

■ How to delete Weekly Timer setting.

[Delete setting of one program]



3

4

1. Press (Weekly) button to select Mode A or Mode B.

2. Press (Weekly) button for 3 seconds to start editing the setting.

3. Press (DAY) button to select a day of the week to edit.

4. Press to select program number. Selected program number will blink.

5. Press (Delete) button. Setting of selected program number is deleted.

6. After deleting, press (Send) button while pointing the remote controller towards the indoor unit for about 3 seconds. Timer LED on the indoor unit blinks rapidly.


After beep sound emitted from indoor unit, Timer LED lights up.

Please ensure that the Timer LED lights up.

● Setting will not change if (Send) button is not pressed.

WEEKLY TIMER OPERATION

Step 3: Copy and cancel the schedule setting.




1

[Delete setting of one day]


1. Press (Weekly) button to select Mode A or Mode B.
2. Press (Weekly) button for 3 seconds to start editing the schedule setting.

2



3

3. Press (DAY) button to select a day of the week to edit.
4. Press (Delete) button for about 10 seconds. Setting for all program numbers will be deleted.
 - If press for a short time, setting for one program number will be deleted.




4

5. After deleting, press (Send) button while pointing the remote controller towards the indoor unit for about 3 seconds. Timer LED on the indoor unit blinks rapidly. After beep sound emitted from indoor unit, Timer LED lights up.

Please ensure that the Timer LED lights up.


 - Setting will not change if (Send) button is not pressed.




5

[Delete Mode A or Mode B]

1. Press (Weekly) button to select Mode A or Mode B.
2. Point the remote controller towards the indoor unit and press (Delete) button for about 10 seconds while Mode A or Mode B display blinks. After beep sound emitted from indoor unit, setting for Mode A or Mode B will disappear.



1





2


NOTE

- If all setting in the remote controller were deleted and pressed (SEND) button, no signal will be transmitted to indoor unit. Timer LED will remain off and no changes will be done to the setting saved in the indoor unit.




INFO FUNCTION

- By pressing  (Info) button, temperature around remote controller and monthly power consumption are displayed on the remote controller.
- After changing the batteries, point the remote controller towards the indoor unit and press  (Info) button. Current date and clock will be transmitted from indoor unit.
- In order to receive information from the indoor unit, the distance between remote controller and receiver from the indoor unit should be within 7ft (2m).





■ To check temperature around remote controller

1

- Press  (Info) button.
Temperature displays for 10 seconds.

■ To check monthly power consumption


Direct the remote controller towards the receiver of indoor unit (within 7ft (2m) in front of indoor unit) and press  (Info) button. Wait for 2 seconds for signal transmission.


While temperature around remote controller is displayed, press  (Info) button repeatedly. The display will show as below:

this month power consumption amount for heating → last month power consumption amount for heating → this month power consumption amount for cooling → last month power consumption amount for cooling → temperature around remote controller → this month power consumption amount for heating cyclically.

- If indication is not appeared, bring remote controller closer to the receiver of the indoor unit.
- Indicated value shall be regarded as a reference only.




■ Current calendar and clock can be retrieved from indoor unit

Point the remote controller towards the receiver of indoor unit (within 7ft (2m) in front of indoor unit) and press  (Info) button. Wait for 2 seconds for signal transmission.

Once received the current date and clock, check whether the information is correct or not by pressing  Clock (Clock) button.


- If there is no power supply to indoor unit or calendar and clock have not been set, INFO function cannot be used for sending or receiving information.

NOTE

- In case failure occurs to the room air conditioner, by pressing  (Info) button, an error code will be displayed.
Point the remote controller towards the receiver of indoor unit (within 7ft (2m) in front of indoor unit) and press  (Info) button. Wait for 2 seconds for signal transmission.
An error code will be displayed.
Call service center and inform the error code.
- Information of "Monthly power consumption" is not available for 6 rooms multi system.
- Info Function to check monthly power consumption.
During installation, in case of power failure or breaker ON / OFF, ensure to set the date and clock for each indoor unit (unit in standby mode or auto restart), for single or multi connection, by pressing  (START / STOP) button.
If this procedure is not carried out successfully, monthly power consumption amount will not be displayed on the remote controller.

OPERATION MODE LOCK

The remote controller can be set to fix the HEATING mode (including FAN), COOLING mode (including FAN) and DEHUMIDIFYING mode (including FAN) operations.




Method to lock HEATING mode (including FAN) operation.

Press (ECO) and (Powerful) buttons simultaneously for about 5 seconds when the remote controller is OFF.

“”, “” and “” will be displayed for about 10 seconds. Later, “” and “” will remain.

This indicates that HEATING mode operation is locked.

When pressing (Mode) button, “” or “” will be displayed.



Method to unlock HEATING mode (including FAN) operation.

Press (ECO) and (Powerful) buttons simultaneously for about 5 seconds when the remote controller is OFF.

All operation mode symbols will appear on the display for about 10 seconds. After that, operation mode symbol before cancellation will be displayed.

This indicates that HEATING mode operation is unlocked.


Method to lock COOLING and DEHUMIDIFYING modes (including FAN) operations.

Press (ECO) and (Silent) buttons simultaneously for about 5 seconds when the remote controller is OFF.

“”, “”, “” and “” will be displayed for about 10 seconds. Later, “” and “” will remain.

This indicates that COOLING and DEHUMIDIFYING mode operation is locked.

When pressing (Mode) button, “”, “” or “” will be displayed.



Method to unlock COOLING and DEHUMIDIFYING modes (including FAN) operations.

Press (ECO) and (Silent) buttons simultaneously for about 5 seconds when the remote controller is OFF.

All operation mode symbols will appear on the display for about 10 seconds. After that, operation mode symbol before cancellation will be displayed.

This indicates that COOLING and DEHUMIDIFYING modes operation is unlocked.


NOTE

- Operation Mode Lock function will not be enabled if Timer setting is in use. Timer setting should be disabled first. Then, Operation Mode Lock function can be enabled.
- HEATING, COOLING and DEHUMIDIFYING mode (including FAN) operations can be unlocked by pressing the (Reset) button. However, by pressing the (Reset) button, all the information saved in the remote controller will disappear. You may need to set the necessary information again.
- For multi connections, unit and mode which is set to lock HEATING and switched on first shall have higher priority. Other units which are chosen to operate at different modes shall be in STANDBY until either the first unit operation is switched off or the mode is selected to be same as the first unit.

CONSTRUCTION AND DIMENSIONAL DIAGRAM

INDOOR UNIT


MODEL RAS-SH07QHLAE
RAS-SH09RHLAE
RAS-SH12RHLAE



CONSTRUCTION AND DIMENSIONAL DIAGRAM FOR OUTDOOR

OUTDOOR UNIT

MODEL RAC-SH09WHLAE
RAC-SH12WHLAE



MAIN PARTS COMPONENT

THERMOSTAT (Room Temperature Thermistor)

Thermostat Specifications

MODEL			RAS-SH07QHLAE, RAS-SH09RHLAE, RAS-SH12RHLAE	
THERMOSTAT MODEL			IC	
OPERATION MODE			COOL	HEAT
TEMPERATURE °C (°F)	INDICATION 16	ON	15.3 (59.5)	16.7 (62.1)
		OFF	15.0 (59)	16.7 (62.1)
	INDICATION 24	ON	23.3 (73.9)	24.7 (76.5)
		OFF	23 (73.4)	24.7 (76.5)
	INDICATION 32	ON	31.3 (88.3)	32.7 (90.9)
		OFF	31.0 (87.8)	32.7 (90.9)

INDOOR FAN MOTOR

Fan Motor Specifications

MODEL	RAS-SH07QHLAE, RAS-SH09RHLAE, RAS-SH12RHLAE
POWER SOURCE	DC: 280V
OUTPUT	30W
CONNECTION	<p>DC 263 ~ 400V (Vm) ○ RED 0V (GND) ○ BLK DC 13.5 ~ 16.5V (Vcc) ○ WHT DC 0 ~ 6.5V (Vsp) ○ YEL FG ○ BLU</p> <p>(Control circuit built in)</p>

OUTDOOR FAN MOTOR

Fan Motor Specifications

ITEM	MODEL	RAC-SH09WHLAE, RAC-SH12WHLAE
POWER SOURCE		DC: 120 ~ 380V
OUTPUT	(W) MAX	47
COIL		<p>RED (U) BLACK (W) WHITE (V)</p>
RESISTANCE VALUE (Ω)	20°C (60°F)	2M
		38.2 ± 3.9

BLU : BLUE
 GRY : GRAY
 BLK : BLACK

YEL : YELLOW
 ORN : ORANGE
 PNK : PINK

BRN : BROWN
 GRN : GREEN
 VIO : VIOLET

WHT : WHITE
 RED : RED

COMPRESSOR MOTOR

Compressor Motor Specifications

MODEL	RAC-SH09WHLAE RAC-SH12WHLAE	
COMPRESSOR MODEL	ASD102SKQA6JK6	
PHASE	SINGLE	
RATED VOLTAGE	AC 220 - 240V	
RATED FREQUENCY	60 Hz	
POLE NUMBER	6	
CONNECTION		
RESISTANCE VALUE (Ω)	20°C (68°F)	2M = 2.167
	75°C (167°F)	-----

CAUTION


When the Air Conditioner has been operated for a long time with the capillary tubes clogged or crushed or with too little refrigerant, check the color of the refrigerant oil inside the compressor. If the color has been changed conspicuously, replace the compressor.

WIRING DIAGRAM

MODEL RAS-SH09RHLAE
 RAS-SH12RHLAE
 RAS-SH07QHLAE


INDOOR UNIT

BLU : BLUE	YEL : YELLOW	BRN : BROWN	WHT : WHITE
GRY : GRAY	ORN : ORANGE	GRN : GREEN	RED : RED
BLK : BLACK	PNK : PINK	VIO : VIOLET	IVO : IVORY



MODEL RAC-SH09WHLAE
 RAC-SH12WHLAE





OUTDOOR UNIT



BLU: BLUE	RED: RED
BLK: BLACK	WHT: WHITE
BRN: BROWN	YEL: YELLOW
GRN: GREEN	GRY: GRAY



CIRCUIT DIAGRAM

Remote Controller



CIRCUIT DIAGRAM

MODEL RAS-SH07QHAE
RAS-SH09RHLAE
RAS-SH12RHLAE



- NOTES:
1. TYPE OF CAPACITOR
F- FILM CAPACITOR
C- CERAMIC CAPACITOR
D- ELETROLYTIC CAPACITOR
2. MOUNTING TYPE
A- AXIAL
R- RADIAL
P- RADIAL(7.5mm PITCH)
H- HAND INSERT
C- SURFACE MOUNT(SMT)
S- IN ADDITION SURFACE MOUNTING

Table with 4 columns: BOARD, TYPE, DRAWING, FORM. Rows include MAIN PWB and #BOARD-AS.

Table with 4 columns: SYMBOL, VALUE, TOLERANCE, WATT, FORM, GROUP, REMARK, ASSY. Lists various resistors (R001-R200).

Table with 4 columns: SYMBOL, VALUE, TOLERANCE, WATT, FORM, GROUP, REMARK, ASSY. Lists various capacitors (C001-C100).

Table with 4 columns: SYMBOL, VALUE, TOLERANCE, WATT, FORM, GROUP, REMARK, ASSY. Lists various diodes (D001-D100).

Table with 4 columns: SYMBOL, VALUE, TOLERANCE, WATT, FORM, GROUP, REMARK, ASSY. Lists various transistors (T001-T100).

Table with 4 columns: SYMBOL, VALUE, TOLERANCE, WATT, FORM, GROUP, REMARK, ASSY. Lists various other components like relays and photo couplers.

Table with 4 columns: SYMBOL, VALUE, TOLERANCE, WATT, FORM, GROUP, REMARK, ASSY. Lists various chip jumpers.

Table with 4 columns: SYMBOL, MODEL, COLOR, FORM, TYP, GRP, ASSY. Lists various LEDs.

Table with 4 columns: SYMBOL, MODEL, FORM, GRP, ASSY. Lists various indicators and connectors.

Table with 4 columns: SYMBOL, VALUE, TOLERANCE, WATT, FORM, GROUP, REMARK, ASSY. Lists various resistors (R200-R400).

Table with 4 columns: SYMBOL, VALUE, TOLERANCE, WATT, FORM, GROUP, REMARK, ASSY. Lists various capacitors (C100-C200).

Table with 4 columns: SYMBOL, VALUE, TOLERANCE, WATT, FORM, GROUP, REMARK, ASSY. Lists various diodes (D100-D200).

Table with 4 columns: SYMBOL, VALUE, TOLERANCE, WATT, FORM, GROUP, REMARK, ASSY. Lists various transistors (T100-T200).

Table with 4 columns: SYMBOL, VALUE, TOLERANCE, WATT, FORM, GROUP, REMARK, ASSY. Lists various other components like relays and photo couplers.

Table with 4 columns: SYMBOL, VALUE, TOLERANCE, WATT, FORM, GROUP, REMARK, ASSY. Lists various chip jumpers.

Table with 4 columns: SYMBOL, MODEL, COLOR, FORM, TYP, GRP, ASSY. Lists various LEDs.

Table with 4 columns: SYMBOL, MODEL, FORM, GRP, ASSY. Lists various indicators and connectors.

Table with 4 columns: SYMBOL, VALUE, VOLTAGE, TYPE, FORM, GROUP, REMARK, ASSY. Lists various capacitors (C200-C300).

Table with 4 columns: SYMBOL, MODEL, FORM, GROUP, ASSY. Lists various diodes (D200-D300).

Table with 4 columns: SYMBOL, MODEL, FORM, GROUP, ASSY. Lists various transistors (T200-T300).

Table with 4 columns: SYMBOL, MODEL, FORM, GROUP, ASSY. Lists various other components like relays and photo couplers.


Table with 4 columns: SYMBOL, VALUE, TOLERANCE, WATT, FORM, GROUP, REMARK, ASSY. Lists various chip jumpers.

Table with 4 columns: SYMBOL, MODEL, COLOR, FORM, TYP, GRP, ASSY. Lists various LEDs.

Table with 4 columns: SYMBOL, MODEL, FORM, GRP, ASSY. Lists various indicators and connectors.

Table with 4 columns: SYMBOL, MODEL, FORM, GRP, ASSY. Lists various indicators and connectors.

CIRCUIT DIAGRAM
MODEL: RAC-SH09WHLAE, RAC-SH12WHLAE
MAIN PWB, HIC PWB, HEATER PWB




MAIN-PCBA				HIC-PCBA				HEATER-PCBA							
Symbol	Reference	Quantity	Notes	Symbol	Reference	Quantity	Notes	Symbol	Reference	Quantity	Notes	Symbol	Reference	Quantity	Notes
R001	1.43M	1R	1/4	R200	10K	1R	1/16	C128	0.1	2R	C	R1	4.7K	5R	1/10
R002	100K	2R		R201	510	5R	1/16	C129	0.1	2R	C	R2	10K	5R	1/10
R004	4.7K	5R	1/4	R202	100K	5R	1/16	C130	0.1	2R	C	R3	10K	5R	1/10
R005	100K	2R		R203	5.1K	5R	1/16	C131	0.1	2R	C	R4	10K	5R	1/10
R006	100K	2R		R204	10K	5R	1/16	C132	0.1	2R	C	R5	10K	5R	1/10
R007	100K	2R		R205	10K	5R	1/16	C133	0.1	2R	C	R6	10K	5R	1/10
R010	0.1	1R	2	R206	10K	5R	1/16	C134	0.1	2R	C	R7	10K	5R	1/10
R011	0.1	1R	2	R207	10K	5R	1/16	C135	0.1	2R	C	R8	10K	5R	1/10
R012	0.1	1R	2	R208	10K	5R	1/16	C136	0.1	2R	C	R9	10K	5R	1/10
R014	0.1	1R	2	R209	10K	5R	1/16	C137	0.1	2R	C	R10	10K	5R	1/10
R015	0.1	1R	2	R210	10K	5R	1/16	C138	0.1	2R	C	R11	100K	5R	1/10
R030	4.7K	5R	1/4	R211	10K	5R	1/16	C139	0.1	2R	C				
R031	4.7K	5R	1/4	R212	10K	5R	1/16	C140	0.1	2R	C				
R102	4.7K	5R	1/4	R213	10K	5R	1/16	C141	0.1	2R	C				
R103	4.7K	5R	1/4	R214	10K	5R	1/16	C142	0.1	2R	C				
R104	4.7K	5R	1/4	R215	10K	5R	1/16	C143	0.1	2R	C				
R105	1.5	5R	1/2	R216	10K	5R	1/16	C144	0.1	2R	C				
R106	4.7K	5R	1/4	R217	10K	5R	1/16	C145	0.1	2R	C				
R107	10	5R	1/8	R218	10K	5R	1/16	C146	0.1	2R	C				
R109	10	5R	1/8	R219	10K	5R	1/16	C147	0.1	2R	C				
R110	10	5R	1/8	R220	10K	5R	1/16	C148	0.1	2R	C				
R112	11K	1R	1/10	R221	10K	5R	1/16	C149	0.1	2R	C				
R113	11K	1R	1/10	R222	10K	5R	1/16	C150	0.1	2R	C				
R114	4.7K	5R	1/10	R223	10K	5R	1/16	C151	0.1	2R	C				
R115	10K	1R	1/10	R224	10K	5R	1/16	C152	0.1	2R	C				
R116	10K	1R	1/10	R225	10K	5R	1/16	C153	0.1	2R	C				
R120	3.3K	5R	1/10	R226	10K	5R	1/16	C154	0.1	2R	C				
R122	10K	1R	1/10	R227	10K	5R	1/16	C155	0.1	2R	C				
R123	10K	1R	1/10	R228	10K	5R	1/16	C156	0.1	2R	C				
R124	10K	1R	1/10	R229	10K	5R	1/16	C157	0.1	2R	C				
R125	10K	1R	1/10	R230	10K	5R	1/16	C158	0.1	2R	C				
R126	10K	1R	1/10	R231	10K	5R	1/16	C159	0.1	2R	C				
R140	20K	5R	1/2	R232	10K	5R	1/16	C160	0.1	2R	C				
R142	10K	1R	1/10	R233	10K	5R	1/16	C161	0.1	2R	C				
R143	10K	1R	1/10	R234	10K	5R	1/16	C162	0.1	2R	C				
R144	10K	1R	1/10	R235	10K	5R	1/16	C163	0.1	2R	C				
R145	10K	1R	1/10	R236	10K	5R	1/16	C164	0.1	2R	C				
R146	10K	1R	1/10	R237	10K	5R	1/16	C165	0.1	2R	C				
R147	10K	1R	1/10	R238	10K	5R	1/16	C166	0.1	2R	C				
R148	10K	1R	1/10	R239	10K	5R	1/16	C167	0.1	2R	C				
R149	10K	1R	1/10	R240	10K	5R	1/16	C168	0.1	2R	C				
R150	10K	1R	1/10	R241	10K	5R	1/16	C169	0.1	2R	C				
R151	10K	1R	1/10	R242	10K	5R	1/16	C170	0.1	2R	C				
R152	10K	1R	1/10	R243	10K	5R	1/16	C171	0.1	2R	C				
R153	10K	1R	1/10	R244	10K	5R	1/16	C172	0.1	2R	C				
R154	10K	1R	1/10	R245	10K	5R	1/16	C173	0.1	2R	C				
R155	10K	1R	1/10	R246	10K	5R	1/16	C174	0.1	2R	C				
R156	10K	1R	1/10	R247	10K	5R	1/16	C175	0.1	2R	C				
R157	10K	1R	1/10	R248	10K	5R	1/16	C176	0.1	2R	C				
R158	10K	1R	1/10	R249	10K	5R	1/16	C177	0.1	2R	C				
R159	10K	1R	1/10	R250	10K	5R	1/16	C178	0.1	2R	C				
R160	10K	1R	1/10	R251	10K	5R	1/16	C179	0.1	2R	C				
R161	10K	1R	1/10	R252	10K	5R	1/16	C180	0.1	2R	C				
R162	10K	1R	1/10	R253	10K	5R	1/16	C181	0.1	2R	C				
R163	10K	1R	1/10	R254	10K	5R	1/16	C182	0.1	2R	C				
R164	10K	1R	1/10	R255	10K	5R	1/16	C183	0.1	2R	C				
R165	10K	1R	1/10	R256	10K	5R	1/16	C184	0.1	2R	C				
R166	10K	1R	1/10	R257	10K	5R	1/16	C185	0.1	2R	C				
R167	10K	1R	1/10	R258	10K	5R	1/16	C186	0.1	2R	C				
R168	10K	1R	1/10	R259	10K	5R	1/16	C187	0.1	2R	C				
R169	10K	1R	1/10	R260	10K	5R	1/16	C188	0.1	2R	C				
R170	10K	1R	1/10	R261	10K	5R	1/16	C189	0.1	2R	C				
R171	10K	1R	1/10	R262	10K	5R	1/16	C190	0.1	2R	C				
R172	10K	1R	1/10	R263	10K	5R	1/16	C191	0.1	2R	C				
R173	10K	1R	1/10	R264	10K	5R	1/16	C192	0.1	2R	C				
R174	10K	1R	1/10	R265	10K	5R	1/16	C193	0.1	2R	C				
R175	10K	1R	1/10	R266	10K	5R	1/16	C194	0.1	2R	C				
R176	10K	1R	1/10	R267	10K	5R	1/16	C195	0.1	2R	C				
R177	10K	1R	1/10	R268	10K	5R	1/16	C196	0.1	2R	C				
R178	10K	1R	1/10	R269	10K	5R	1/16	C197	0.1	2R	C				
R179	10K	1R	1/10	R270	10K	5R	1/16	C198	0.1	2R	C				
R180	10K	1R	1/10	R271	10K	5R	1/16	C199	0.1	2R	C				
R181	10K	1R	1/10	R272	10K	5R	1/16	C200	0.1	2R	C				
R182	10K	1R	1/10	R273	10K	5R	1/16	C201	0.1	2R	C				
R183	10K	1R	1/10	R274	10K	5R	1/16	C202	0.1	2R	C				
R184	10K	1R	1/10	R275	10K	5R	1/16	C203	0.1	2R	C				
R185	10K	1R	1/10	R276	10K	5R	1/16	C204	0.1	2R	C				
R186	10K	1R	1/10	R277	10K	5R	1/16	C205	0.1	2R	C				
R187	10K	1R	1/10	R278	10K	5R	1/16	C206	0.1	2R	C				
R188	10K	1R	1/10	R279	10K	5R	1/16	C207	0.1	2R	C				
R189	10K	1R	1/10	R280	10K	5R	1/16	C208	0.1	2R	C				
R190	10K	1R	1/10	R281	10K	5R	1/16	C209	0.1	2R	C				
R191	10K	1R	1/10	R282	10K	5R	1/16	C210	0.1	2R	C				
R192	10K	1R	1/10	R283	10K	5R	1/16	C211	0.1	2R	C				
R193	10K	1R	1/10	R284	10K	5R	1/16	C212	0.1	2R	C				
R194	10K	1R	1/10	R285	10K	5R	1/16	C213	0.1	2R	C				
R195	10K	1R	1/10	R286	10K	5R	1/16	C214	0.1	2R	C				
R196	10K	1R	1/10	R287	10K	5R	1/16	C215	0.1	2R	C				
R197	10K	1R	1/10	R288	10K	5R	1/16	C216	0.1	2R	C				
R198	10K	1R	1/10	R289	10K	5R	1/16	C217	0.1	2R	C				
R199	10K	1R	1/10												

PRINTED BOARD LOCATION DIAGRAM

MODEL: RAS-SH07QHLAE, RAS-SH09RHLAE, RAS-SH12RHLAE


MAIN P.W.B

Marking on P.W.B




RECEIVING & SENSOR P.W.B


Marking on P.W.B



MAIN PWB
 MODEL RAC-SH09WHLAE
 RAC-SH12WHLAE




Top side




Bottom side

RELAY PWB

MODEL RAC-SH09WHLAE
RAC-SH12WHLAE




Top side



Bottom side


BLOCK DIAGRAM



BASIC MODE



Operation mode	Fan	Cooling	Dehumidifying	Heating	Auto	
Basic operation of start/stop button						
Timer functions	Off-timer					
	On-timer					
Fan speed mode (indoor fan)	Auto	<p>Changes from "Hi" to "Med" or "Lo" depending on room temperature.</p> <p>1. Runs at "Hi" until room temperature reaches to "setting temperature-SFTDSC" after operation is started. 2. Runs at "ultra-Lo" when thermo is off.</p>		<p>Set to "ultra-Lo", "Silent", "Lo", "Med", "Hi", "ultra-Hi" or "stop" depending on the room temperature, time and heat exchanger temperature. Set to "stop" if the heat exchanger temperature is "DNZKOF" during Thermo OFF. (When reach at "DNZKON", fan speed set to "ultra-Lo" again.)</p>	<p>Operating mode is judged by room temperature.</p> <p>(1) Judging by room temperature (Initial judgement)</p> <p>(a) Conditions for judgment (any of the followings).</p> <ul style="list-style-type: none"> When auto operation is started after the previous auto mode operation. When auto operation is started after the previous manual mode operation. When the operating mode is switched to auto while operating at manual mode. <p>(b) Judging method</p> <ul style="list-style-type: none"> [Cooling] : Room temperature \geq Remote controller setting [Heating] : Room temperature $<$ Remote controller setting 	
	Hi	Operates at "Hi" regardless of the room temperature.	Set to "ultra-Hi" when the compressor runs at cold dash mode speed, and to "Hi" in other modes. Runs at "ultra-Lo" when thermo is off.		<p>Set to "ultra-Lo", "Silent", "Lo", "Med", "Hi", "ultra-Hi" or "stop" depending on the room temperature, time and heat exchanger temperature. Set to "stop" if the heat exchanger temperature is "DNZKOF" during Thermo OFF. (When reach at "DNZKON", fan speed set to "ultra-Lo" again.)</p> <p>Set to "ultra-Hi" when the compressor is running at maximum speed during hot dash or when recovered from defrosting.</p>	<p>(2) Judging by room temperature (continuous judgement)</p> <p>(a) Judging condition</p> <ul style="list-style-type: none"> Operating mode will be judge again after auto mode interval time (1) 1st interval [auttmn1_8u] (2) 2nd interval [auttmn2_8u] (3) 3rd and next interval [auttmn3_8u] <p>(b) Judging method</p> <ul style="list-style-type: none"> Judging method will follow as below Final set temperature is remote controller setting including shift value <p>[Current operation is COOLING]</p> <ul style="list-style-type: none"> Room temperature \leq Final set temperature - [nwautw_8u], change to HEATING Room temperature $>$ Final set temperature - [nwautw_8u], continue in COOLING <p>[Current operation is HEATING]</p> <ul style="list-style-type: none"> Room temperature \geq Final set temperature + [nwautc_8u], change to COOLING Room temperature $>$ Final set temperature + [nwautc_8u], continue in HEATING
	Med	Operates at "Med" regardless of the room temperature.	Operates at "Med" regardless of the room temperature. Runs at "ultra-Lo" when thermo is off.		<p>Set to "ultra-Lo", "Silent", "Lo", "Med", "Hi", "ultra-Hi" or "stop" depending on the room temperature, time and heat exchanger temperature. Set to "stop" if the heat exchanger temperature is "DNZKOF" during Thermo OFF. (When reach at "DNZKON", fan speed set to "ultra-Lo" again.)</p>	
	Lo	Operates at "Lo" regardless of the room temperature.	Operates at "Lo" regardless of the room temperature. Runs at "ultra-Lo" when thermo is off.	Set to "Lo" in modes other than when the compressor stops.	<p>Set to "ultra-Lo", "Silent", "Lo", "Med", "Hi", "ultra-Hi" or "stop" depending on the room temperature, time and heat exchanger temperature. Set to "stop" if the heat exchanger temperature is "DNZKOF" during Thermo OFF. (When reach at "DNZKON", fan speed set to "ultra-Lo" again.) The fan speed is controlled by the heat exchanger temperature; the overload control is executed as in the following diagram:</p>	
	Silent	Operates at "Silent" regardless of the room temperature.	Operates at "Silent" regardless of the room temperature. Runs at "ultra-Lo" when thermo is off.	Set to "Silent" in modes other than when the compressor stops.		
Basic operation of temperature controller	Performs only fan operation at the set speed regardless of the room temperature.	See page 49.	See page 53.	See page 57.	Follow basic cooling or heating operation	

Basic Cooling Operation



Notes:


- (1) Condition for entering into Cool Dashed mode. When fan set to "Hi" or "Auto and when the compressor speed (P section) due to temperature difference between setting temperature (including the correction shift only) and room temperature is CMAX or higher.
- (2) Cool Dashed will release when i) a maximum 25 minutes is lapsed and ii) room temperature is lower than set temperature -3°C (thermo off) and iii) when room temperature has achieved setting temperature -1°C then maximum Cool Dashed time will be revised to 20 minutes. And iv) indoor fan is set to Lo and Med fan mode and v) change operation mode.
- (3) During Cool Dashed operation, thermo off temperature is set temperature (with shift value) -3°C . After thermo off, operation continue in Fuzzy control mode.
- (4) Compressor minimum "ON" time and "OFF" time is 3 minutes.
- (5) During normal cooling mode, compressor maximum rpm CMAX will maintain for 60 minutes if indoor temperature is lower than CLMXTP. No time constrain if indoor temperature is higher than CLMXTP.
- (6) When fan is set to "Hi", compressor rpm will be limited to CSTD.
- (7) When fan is set to "Med", compressor rpm will be limited to CJKMAX.
- (8) When fan is set to "Lo", compressor rpm will be limited to CBEMAX.
- (9) During Cool Dashed, when room temperature reaches set temperature -1°C compressor rpm is actual rpm x DWNRATEC.



Notes :

- (1) Pressing the "POWERFUL" button will reduce the temperature setting by PWSFTC.
- (2) The powerful operation is for 20 minutes after setting.
- (3) Operation is continued forcibly thermo-ON for 20 minutes after the powerful operation is finished.
- (4) Pressing the "START/STOP" button and "POWERFUL" button during powerful operation will cancel the powerful operation.
- (5) If the sleep timer is set during powerful operation, the powerful operation will be canceled.
- (6) When the powerful operation is set, the fan speed will be set to "HIGH" and the compressor's maximum speed will be set to CMAX2 during powerful operation. The compressor's lower limit speed is CKYMIN_PW.
- (7) The fan speed increases by FNUPPW_C.
- (8) After the powerful operation is ended, the system automatically operates with the previous settings used before the powerful operation.


Dehumidifying



Notes:

- (1) If the room temperature is (cooling preset temperature) - (1.33°C) or less after 30 seconds from starting the operation, the operation is done assuming as the preset temperature = (room temperature at the time) - (2°C).
- (2) The indoor fan is operated in the "Lo" or "Silent" mode. During thermo OFF, indoor fan will be OFF 5 minutes and ON for 1 minute
- (3) When the operation is started by the thermostat turning ON, the start of the indoor fan is delayed 32 seconds after the start of compressor operation.
- (4) The compressor is operated forcedly for 3 minutes after operation is started.
- (5) The minimum ON time and OFF time of the compressor are 3 minutes.


Dehumidifying Powerful Operation



Notes :

- (1) Pressing the "POWERFUL" button will reduce the temperature setting by PWSFTSD.
- (2) The powerful operation is for 20 minutes after setting.
- (3) Operation is continued forcibly thermo-ON for 20 minutes after the powerful operation is finished.
- (4) Pressing the "START/STOP" button and "POWERFUL" button during powerful operation will cancel the powerful operation.
- (5) If the sleep timer is set during powerful operation, the powerful operation will be canceled.
- (6) If the differential (the room temperature - the temperature setting) is "the differential $\geq 3\text{ }^{\circ}\text{C}$ " after powerful setting, the compressor's maximum speed during powerful operation will be set to SDMAX. Then the differential reduce "the differential $\leq 2.33\text{ }^{\circ}\text{C}$ " during powerful operation, the compressor's speed will be set to SDRPM.
If the differential (the room temperature - the temperature setting) is "the differential $< 3\text{ }^{\circ}\text{C}$ " after powerful setting, the compressor's minimum speed during powerful operation will be set to SDRPM.
- (7) After the powerful operation is ended, the system automatically operates with the previous settings used before the powerful operation.


ECO



Notes:

- Can't set POWERFUL and ECO at the same time.
- During FAN operation, can't set ECO.

Clean Operation




Notes :

- (1) During CLEAN operation period, heating mode will change to fan mode when HEX temperature is "CLNEVP" or more except for 3 minutes operation.
- (2) For multi connections, CLEAN operation is limited to fan mode.


REFRIGERATING CYCLE DIAGRAM

RAS-SH07QHLAE / (MULTI ONLY)
 RAS-SH09RHLAE / RAC-SH09WHLAE
 RAS-SH12RHLAE / RAC-SH12WHLAE

COOLING, DEHUMIDIFYING, DEFROSTING



HEATING



AUTO SWING FUNCTION

INPUT SIGNAL	PRESENT CONDITION		OPERATING SPECIFICATION	REFERENCE
	OPERATION	OPERATION MODE AIR DEFLECTOR		
KEY INPUT	STOP	EACH MODE	ONE SWING (CLOSING AIR DEFLECTOR) ① DOWNWARD ② UPWARD	INITIALIZE AT NEXT OPERATION.
			STOP AT THE MOMENT.	
DURING OPERATION			START SWINGING ① DOWNWARD ② UPWARD ③ DOWNWARD	
		COOL DRY	STOP AT THE MOMENT.	
THERMO. ON (INTERNAL FAN ON)			STOP SWINGING	
			TEMPORARY STOP	
THERMO. ON (INTERNAL FAN OFF)		COOL DRY	START SWINGING AGAIN.	
		DRY	STOP SWINGING TEMPORARILY. (SWING MODE IS CLEARED IF SWING COMMAND IS TRANSMITTED DURING TEMPORARY STOP.)	
MAIN SWITCH ON	STOP	COOL DRY	INITIALIZE ① DOWNWARD ② UPWARD	
			STOP DURING ONE SWING	
MAIN SWITCH OFF		EACH MODE	ONE SWING (CLOSING AIR DEFLECTOR) ① DOWNWARD ② UPWARD	INITIALIZE AT NEXT OPERATION.
			INITIALIZING CONDITION OF EACH MODE.	
CHANGE OF OPERATION		EACH MODE	STOP SWINGING AND MODE BECOMES INITIALIZING CONDITION.	
			DURING SWINGING	

1. Control power circuit




Fig. 1-1

- An AC power supply from indoor unit passes through the 3.15A fuse, varistor (VA001), and noise filter circuit and rectified and smoothed by DB1 and C003 to become a DC current 325 V. It is then supplied to indoor fan motor drive circuit, and switching power circuit.
- The switching power circuit, as controlled by IC001, drives the primary winding of the transformer (T001) to produce a specified voltage at the output winding. [The output terminal (pin ⑤) of IC001 has a switching voltage. But it changes in voltage peak and oscillation period depending on the power load. usually, the oscillation frequency when the air condition operation is about 64.5 kHz. In the standby state, the oscillation frequency is lowered to a level as low as 64.5 kHz or so to reduce the standby power.]
- The outputs of the output windings of the transformer is rectified and smoothed to become DC voltages at primary 18.5 V, 12 V, and 8.5 V respectively. The primary 18.5 V is supplied to the drive circuit of the indoor fan motor, the 12 V is supplied to each vane motor and to the drive circuits of the cleaning unit driving motor and other equipment, and the 8.5 V is adjusted to a stable 5 V by IC101 and supplied to the microcomputer peripheral circuit.

Check

If a failure in a part or circuit has produced an abnormal current in the power supply, the 3.15A fuse will melt down to prevent further damage. If the 3.15A fuse melts down, check the indoor fan motor, switching electrical circuit, and other components and replace any defective part.

Check

If an abnormally high voltage is applied to the power supply, the 3.15A fuse and varistor (VA001) will prevent further damage. If a high voltage results in the 3.15A fuse melted down, the varistor (VA001) should have deteriorated and destroyed. Therefore replace it at the same time.

Caution

The primary circuit of the transformer (T001) has a voltage to ground. Guard against electric shocks.

2. Reset Circuit




Fig. 3-1

Timing chart




Fig. 3-2

- Reset circuit is to initialize the indoor unit microcomputer when switching ON the power or after recovering from power failure.
- Low voltage at pin ⑬ resets the microcomputer and Hi activates the microcomputer.
- Waveform of each part when switching ON the power and when shutting down is shown in the Fig. 3-2.
- After switching ON the power, ① pin of IC501 supply voltage and ⑬ pin of microcomputer becomes Hi when DC5V line rises and reaches approximately 4.4V or higher. Then, resetting will be cancelled and microcomputer starts operating.
- After shutting down the power, ① pin of IC501 supply voltage and ⑬ pin of microcomputer becomes Lo when DC5V line falls and reaches approximately 4.2V or lower. Then, the microcomputer will be in reset condition.

3. Drive circuit of the indoor fan motor





Fig. 3-1

< The circuit check (For test) >

Name	Test point	Test voltage
Motor drive power	CN2 ① pin- ④ pin	About 325V
Motor control power	CN2 ⑤ pin- ④ pin	About 15V
Motor speed signal	CN2 ⑥ pin- ④ pin	About 2-6V
Motor rotation speed debug	CN2 ⑦ pin- ④ pin	About 7.5V

< Pin 6 - Pin 4 voltage one example >



- * The voltage above is all motor operation vol. when you start the test, take care of your connector, do not touch the different pin together.
- * The voltage of pin ⑥ - pin ④, pin ⑦ - ④ maybe different from above.

- * The different mode maybe have different FAN rotation speed.

< Typical circuit waveform >




Fig. 3-2

- The indoor fan motor receives VDC (motor drive power supply), VCC (power supply for the control circuit inside the motor), and VS (speed command voltage) from CN2. The indoor fan motor returns an FG signal of a frequency that matches the rotation speed.
- VCC stabilizes the primary 18.5 V power supply into 15 V by using Q201 and supplies it.
- While on standby for a remote control signal, the Q201 shuts down the VCC and reduces the standby power.
- The VS receives a command voltage from the microcomputer. The VS terminal undergoes an analog voltage that matches the Lo level time ratio of the pulse signal from pin ⑥ of the microcomputer. (See Fig. 3-2.)
- The FG terminal undergoes a signal of 12 pulses per revolution of the motor shaft. By counting the pulse rate, the microcomputer recognizes the motor speed, thereby performing feedback control.

4. Buzzer Circuit




Fig.4-1 Buzzer Circuit

- When the buzzer sounds, an approx. 3.9kHz square signal is output from buzzer output pin (32) of the micro computer. After the amplitude of this signal has been set to 12Vp-p by a transistor, it is applied to the buzzer. The piezoelectric element in the buzzer oscillates to generate the buzzer's sound.




Fig.4-2 Buzzer Operation

5. Remote control reception circuit




Fig.5-1

[Typical communication waveform]





Fig.5-2

- An infrared signal from the remote control unit is converted to an electrical signal by the remote control light-receiving unit and is received by the microcomputer. Data is transmitted as digital data 0 and 1 by changing the interval of the basic pulses at about 420 μs.

6. Room temperature, heat exchanger thermistor circuits



- The thermistor is used for detecting the room temperature and indoor unit heat exchanger pipe temperature.
- The thermistor is a sensor that changes its resistance value according to the temperature of the element and the microcomputer recognizes the analog voltage provided by the resistance voltage division with the fixed resistor as temperature signals.
- The relationship between the temperature of the thermistor and the circuit voltage is roughly as shown in Fig.6-1 and Fig.6-2. When it is easy to measure between the terminals of CN4 in actual measurement, use the graph of Fig. 6-3 "Thermistor both ends voltage".




Fig. 6-1




Fig. 6-2




Fig. 6-3

7. Dip switch




Fig. 7-1 Dip switch Circuit

- Fig. 7-1 shows the dip switch circuit; the table shown in Fig. 7-2 are function and setting position from ①—⑥ of the switch No.

SW No.	I T E M	F U N C T I O N					
1	AUTO RESTART	OFF*	ENABLE	ON	DISABLE		
2	CARD KEY MODE	OFF*	DISABLE	ON	ENABLE		
3	CARD KEY LOGIC SELECT	OFF*	INPUT HIGH ACTIVE	ON	INPUT LOW ACTIVE		
4	HEATING/COOLING ONLY MODE SELECT	OFF*	HEATING & COOLING	OFF	HEATING ONLY	ON	COOLING ONLY
5	HEATING/COOLING ONLY MODE SELECT	OFF*		ON	HEATING ONLY	OFF	
6	REMOCON ID SELECT	OFF*	FACTORY	ON	SELECT		


Fig. 7-2 Functions of Dip switch

NOTE:


* Marking is position of shipping [FACTORY default setting]

8. Initial Setting Circuit (IC531)

- When power is supplied, the microcomputer reads the data in IC531 (E²PROM) and sets the preheating activation value and the rating and maximum speed of the compressor, etc. to their initial values.
- Data of self-diagnosis mode is stored in IC531; data will not be erased even when power is turned off.




9. Temporary Switch Circuit



- The temporary switch is used to operate the air conditioner temporarily when the wireless remote control is lost or faulty.
- The air conditioner operates in the automatic mode by pressing the temporary switch. If the power switch is set to OFF then ON it also operates in the automatic mode when the temporary switch is pressed.

10. Infrared human presence sensor circuit



- With the infrared sensor, the air conditioner can detect the activity level in a room and adjust the temperature and humidity automatically, thus achieving the purpose of energy saving.
- When the activity level in a room is detected, the infrared sensor will be in operation. And a low-voltage output from the infrared sensor P.W.B. will be magnified by the amplifier comparator and be transformed the digital signal to microcomputer (IC601).

Infrared sensor

The infrared sensor output is [Hi] when the activity level is not detected. On the contrary, output is [Lo].

The area in front of the indoor unit is divided into 3 parts (the left area, central area and right area). According to the 3 areas, the infrared sensor detects the position of people.

The left-hand chart is displaying the operation of the infrared sensor when detecting the person moving from the left area to the right.

11 . Indoor/outdoor communication circuits




Fig. 11-1





Fig. 11-2

- Indoor and outdoor communications are conducted by using lines 2 and 3 of F cable. Line 2 of F cable is shared with a transmission channel that powers the outdoor unit.
- Data communicated between the indoor and outdoor units are outputted from the microcomputer as serial signals and are transmitted as demodulated by a 30 kHz carrier wave. (Both the indoor and outdoor microcomputers directly output a signal demodulated at 30 kHz.)


Check

If a cable poorly inserted in the indoor terminal board or some other failure overheats the terminal board and the temperature fuse of the terminal board blows out, the power to the indoor communication circuit will be shut down to stop the communications function.

Check

If communication fails between the indoor and outdoor units for some reason, the product will give a self-diagnosis display either by "the timer lamp blinking 3 times" or "the timer lamp blinking 12 times" depending on the cause.

Indoor/Outdoor communication fault circuit judgement



1. Failure happen during unit running

- 【If ① failure】 Outdoor: LD301 blinking 9 times / Indoor: no failure display
- 【If ② failure】 Outdoor: LD301 blinking 9 times / Indoor: the timer lamp blinking 3 times
- 【If ③ failure】 Outdoor: LD301 blinking 9 times / Indoor: no failure display
- 【If ④ failure】 Outdoor: LD301 blinking 9 times / Indoor: the timer lamp blinking 3 times

2. Failure happen during standby mode but outdoor unit not yet enter hibernation mode

- 【If ① failure】 Outdoor: LD301 blinking 9 times / Indoor: the timer lamp blinking 12 times
- 【If ② failure】 Outdoor: LD301 blinking 9 times / Indoor: the timer lamp blinking 3 times
- 【If ③ failure】 Outdoor: LD301 blinking 9 times / Indoor: the timer lamp blinking 12 times
- 【If ④ failure】 Outdoor: LD301 blinking 9 times / Indoor: the timer lamp blinking 3 times

3. Failure happen during standby mode but outdoor unit already enter hibernation mode

- 【If ① failure】 Outdoor: no failure display / Indoor: the timer lamp blinking 12 times
- 【If ② failure】 Outdoor: no failure display / Indoor: the timer lamp blinking 3 times
- 【If ③ failure】 Outdoor: no failure display / Indoor: the timer lamp blinking 12 times
- 【If ④ failure】 Outdoor: no failure display / Indoor: the timer lamp blinking 3 times

When outdoor unit is in hibernation mode, outdoor microcomputer is off, so the outdoor unit can't display the failure.

12. Stepping motor drive circuit




Fig. 12-1

[Connector circuit waveform while the motor runs]
 Voltage waveforms of different phases as viewed from the OV line while the motor rotor is turning counterclockwise as viewed from the shaft side




Fig. 12-2

- Each stepping motor runs as excited in 1 or 2 phases at 100 PPS or 200 PPS.
- The excitation pattern passes the microcomputer (IC601) and then the driver IC and excites the coil of each stepping motor.
- Some models not need to install the horizontal sweep motor.

13. Run status and alarm signal output circuit




Fig.13-1

Fig.13-1 is the control circuit of run status and signal output in main PWB. The pin ② of CN5 is used to show run status and the pin ④ of CN5 is used to warn people when failure occurrence. If customer want to use this function, need to use the adapter (sold separately) to achieve it. the adapter is optional and the detail circuit refer to following circuit.




Fig.13-2

LED1 is on When air-condition is running and is off When air-condition is stopping. We can know the status of air-condition by LED1. LED2 is off When air-condition in normal condition and is on when air-condition in failure occurrence, we can repair it in time. The brightness of the lamp (LED1, LED2) can be determined by adjusting the resistance (R5, R6) value.

※ The adapter must be used because of noise interference. The noise will cause air-condition failure. the voltage from customer's home supply to adapter must be in the 5~24V, the current is less than 10mA. If the voltage is lower than 5V, optocouplers will not be action; once the voltage is higher than 24 V, optocouplers adapter will be damaged.

DESCRIPTION OF MAIN CIRCUIT OPERATION

MODEL RAC-EH09WHLAB, RAC-EH12WHLAB

1. Power Circuit.




Fig. 1-1

※ This circuit rectifies the AC voltage 115V applied between terminal L and N and creates a DC voltage.

The voltage become 250-270V when the compressor is operated.

※ Importance components.

- (1) Inverter circuit for compressor (Q901 to Q906).
The elements constitute the inverter part.
- (2) Diode stack (DB1, DB601, DB602).
The diode stack rectify AC Voltage 115V applied between the Terminal board L and N to DC Voltage.
- (3) Smoothing capacitor (C021 to C022, 2000uF, 220V).

<Reference>

※ When the inverter circuits for compressor (Q901 to Q906) have a failure or improper connection, the compressor may stop immediately after its starts, due to "Abnormal low speed", "Switch failure", "IP Stop", etc.

<Reference>

※ When the diode stack (DB602) has failure, DC voltage can not be generated, completely disabling the operation of the compressor. Also note that 2A fuse may have blown.

<Reference>

※ The smoothing capacitor smoothes (average) voltage rectifier by the diode bridge.




Fig. 1-2

(4) IGBT for the power factor improvement (Q601).

<Reference>
 ※ It will improve efficiency during compressor load become heavy when current flow thru the chopper period of Q601.

(5) Surge absorber, varistor 1 and 2.
 The surge absorber and varistor absorb exogenous surge, including inductive lightning.

<Reference>
 ※ Be sure to ground the surge absorber and varistor. without grounding, the surge absorber and varistor do not operate normally.

(6) Noise filter (C004, C005, C015, C016, NF Coil).
 The noise filter absorb electrical noise generated when the compressor operates and when exogenous noise is mixed through the power line. In order to protect electronic parts.

<Reference>
 ※ Without grounding, the noise filter on the left do not operated normally.

DESCRIPTION OF MAIN CIRCUIT OPERATION

MODEL RAC-SH09WHLAE, RAC-SH12WHLAE

1. Power Circuit.




Fig. 1-1

※ This circuit rectifies the AC voltage 230V applied between terminal L and N and creates a DC voltage.

The voltage become 320-360V when the compressor is operated.

※ Importance components.

- (1) Inverter circuit for compressor (Q901 to Q906).
The elements constitute the inverter part.
- (2) Diode stack (DB602).
The diode stack rectify AC Voltage 230V applied between the Terminal board L and N to DC Voltage.
- (3) Smoothing capacitor (C021 to C022, 500uF, 450V).
- (4) IGBT for the power factor improvement (Q601).
- (5) Surge absorber, varistor 1 and 2.
The surge absorber and varistor absorb exogenous surge, including inductive lightning.
- (6) Noise filter (C001, C002, C006, C007, C013, C014, NF Coil). The noise filter absorb electrical noise generated when the compressor operates and when exogenous noise is mixed through the power line. In order to protect electronic parts.

<Reference>

- ※ When the inverter circuits for compressor (Q901 to Q906) have a failure or improper connection, the compressor may stop immediately after its starts, due to "Abnormal low speed", "Switch failure", "IP Stop", etc.

<Reference>

- ※ When the diode stack (DB602) has failure, DC voltage can not be generated, completely disabling the operation of the compressor. Also note that 2A fuse may have blown.

<Reference>

- ※ The smoothing capacitor smoothes (average) voltage rectifier by the diode bridge.

<Reference>

- ※ It will improve efficiency during compressor load become heavy when current flow thru the chopper period of Q601.

<Reference>

- ※ Be sure to ground the surge absorber and varistor. without grounding, the surge absorber and varistor do not operate normally.

<Reference>

- ※ Without grounding, the noise filter on the left do not operated normally.

2. Power Circuit (Low Voltage)





Fig. 2-1

- The 230V VAC voltage is rectified to DC voltage (B-12V, 16V, 12V, 5V) pass through switching control IC (IC1), switching transformer.
 - (1) B-12 Power supply for electrical expansion valve.
 - (2) 16V Power supply for driver circuit of compressor and fan motor, IGBT action.
 - (3) 12V Power supply for 4-way valve relay, power relay, motor current amplification.
 - (4) 5V Power supply for microcomputer, peripheral circuit.



※ Because high voltage flows, be careful about electric shock. Also, be careful about short-circuit accidents by improper connection of measuring instruments, which can damage the board.

3. Power Supply Circuit for Board

The voltage specification of the power supply circuit are as follow.

<Checking points>

Output Name	Voltage Specifications Value	Main Load	±Measurement Position	Example of failure mode for each output failure (Reference)
5V Output	$5 \pm 0.4 \text{ V}$	Microcomputer Thermistor	Tester (+) terminal: J96 (5V indication) Tester (-) terminal: J138 (0V indication)	The troubleshooting lamp LD301 does not indicate and the outdoor unit does not operate.
12V Output	$12 \pm 1 \text{ V}$	Microcomputer IC2, 3 and 4 Relay Circuit	Tester (+) terminal: J139 (12V indication) Tester (-) terminal: J138 (0V indication)	The troubleshooting lamp LD301 does not indicate and the outdoor unit does not operate.
16V Output	$15.5 \pm 1.5 \text{ V}$	Compressor Inverter Circuit Fan Inverter Circuit	Tester (+) terminal: J111 (16V indication) Tester (-) terminal: J138 (0V indication)	The troubleshooting lamp LD301 blinks 3, 4 or 12 times and the outdoor unit stops.
B-12V Output	$12 \begin{smallmatrix} +3 \\ -1 \end{smallmatrix} \text{ V}$	Expansion Valve	Tester (+) terminal: J133 (B-12V indication) Tester (-) terminal: J130 (B-0V indication)	The troubleshooting lamp LD301 blinks 5 times and the outdoor unit stops.

※ When checking each voltage, if the voltage specifications above are met, the power supply circuit for the board is functioning normally.

4. Temperature Detection Circuit




Fig.4-1

- OH thermistor circuit detect the temperature at the surface of compressor head, DEF thermistor circuit detect the defrosting operation temperature.
- A thermistor is a negative resistor element which has characteristics that the higher(lower) the temperature, the lower(higher) the resistance.
- When the compressor is heated, the resistance of the OH thermistor becomes low and $\oplus 5V$ is divided by OH thermistor and R301 and the voltage at pin (78) of microcomputer.
- Compare the voltage at microcomputer pin (78) and setting value stored inside. If the value exceed the set value, microcomputer will judge that the compressor is overheated and stop the operation.
- The microcomputer read the outdoor temperature by Outside Air thermistor and transfer it to the indoor unit, thus controlling the compressor rotation speed according to the set value in the EEPROM of indoor unit and switching the operation mode (outdoor fan on/off etc.) to DRY mode.

Below table show the typical values of outdoor temperature in relation to the voltage.

Table 4-1

Outside Air Temperature (°C)	-10	0	10	20	30	40
Voltage at both side of R303 (V)	1.19	1.69	2.23	2.75	3.22	3.62

<Reference>

When the thermistor is open, open condition or disconnect, microcomputer pin (78)(79)(83) are approx. 0V;

When thermistor is shorted, they are approx. 5V and LD301 will blink 7 times.

However, an error is detected when only the OH thermistor is shorted and will enter blinking mode after 12 minutes start the compressor operation.

5. Outdoor DC fan motor control circuit

- This model is built with DC fan motor control circuit inside outdoor electrical unit.




Fig 6-1

This DC fan motor is control by outdoor microcomputer that follow the operating instruction received from indoor microcomputer. The DC current that flow from R741 will presume actual operation speed and control the rotation to follow the operating instruction. Based on this DC current it will detect a over current and other fan motor failure.

(1) Fan motor speed controller during starting

Due to the interference of strong wind etc., operation movement is changed based on fan direction and rotation speed as shown below during starting of operation.

In addition, the fair wind is define as wind that blow to outside direction using Mouth Ring part. At strong and contrary wind ... The rotational speed is not controlled as to protect the equipment and fan will rotate reversely depend on the wind. Automatically start when wind condition become weak.

At contrary wind ... The rotational speed is controlled in fair wind direction after it slowly reduce the speed and finally stop.

At fair wind ... The rotational speed is controlled as it is.

At strong fair wind ... The rotational speed is not controlled as to protect the equipment and fan will rotate reversely depend on the wind. Automatically start when wind condition become weak.

(2) Fan motor speed controller during unit operating

There is a case where fan rpm is reducing during rotating caused by interference of strong wind

If this condition continue in long period, fan will stop rotating. (LD301 : 11 times blinking)


The unit will restart according to control as per during start (1).

(3) Method of confirming self diagnosis LD301 lamp : 12 times blinking

If the unit stop and LD301 on the pwb blinking 12 times [fan lock stop is detected], follow below steps to confirm it.

1. Fan lock stop is detected when something has disturb the fan rotation by inserting material into propeller fan or ice has growing inside outdoor unit caused by snow.
Remove it if found something is bloking the fan.
2. Confirmed that CN24 connector is securely inserted. Fan lock stop is detected also when connector is not properly inserted. Please securely insert if found any disconnection.
3. Fan lock stop also can be detected where strong wind blown surrounding the unit.
Please confirm after restart the unit. (It may take few minutes to operate the compressor)
It is not a malfunction of electrical unit or fan motor if the unit run continuesly after restart the unit.
4. Check fan motor condition as below procedure.

[Checking Fan Motor] procedure



5. Reconnect again fan motor connector (CN24).

※Please confirm above checking procedure if found 2Afuse blown.

If fan motor is broken, replace both electrical unit and fan motor.

Caution

※Beware of electric shock due to high voltage when conducting an operation check.

Power supply for DC fan motor and compressor is common (DC260-360V).

6. Electric expansion valve circuit




Fig. 6-1

- The electric expansion valve is driven by DC12V. Power is supplied to 1 or 2 phases of 4-phase winding to switch magnetic pole of winding in order to control the opening degree.
- Relationship between power switching direction of phase and open/close direction is shown below. When power is supplied, voltages at pins ④ to ① of CN15 are about 0.9V and 12V when no power is supplied. When power is reset, initial operation is performed for 10 or 20 seconds. During initial operation, measure all voltages at pin ④ to ① of CN15 by using a multimeter. If there is any pin with voltage that has not changed from 0.9V or 12V, expansion valve or microcomputer is broken.
- Fig. 6-2 shows logic waveform when expansion valve is operating.

Table 6-1

CN15 pin no.	Wire	Drive status							
		1	2	3	4	5	6	7	8
①	WHT	ON	ON	OFF	OFF	OFF	OFF	OFF	ON
②	YEL	OFF	ON	ON	ON	OFF	OFF	OFF	OFF
③	ORG	OFF	OFF	OFF	ON	ON	ON	OFF	OFF
④	BLU	OFF	OFF	OFF	OFF	OFF	ON	ON	ON

Operation mode
 1→2→3→4→5→6→7→8 VALVE CLOSE
 8→7→6→5→4→3→2→1 VALVE OPEN




Fig. 6-2

With expansion valve control, opening degree is adjusted to stabilize target temperature by detecting compressor head temperature. The period of control is about once per 20 seconds and output a few pulse.

7. Reversing valve (4-way valve) control circuit

- This model equipped with a reversing valve (4-way valve).
- The reversing valve (4-way valve) "slides" the valve in the specified direction for each operating mode and switches the route refrigerant and holds the route with a built-in permanent magnet.
- According to an operation command from the indoor unit microcomputer, the reversing valve (4-way valve) control circuit applies current to the reversing valve (4-way valve) coil in the specified direction, for each operating mode and slide the valve.
- Just before the compressor starts operation, the current is applied twice at the interval of 1 sec as shown in Fig.2-1.
- During forced cooling operation, just after the forced cooling switch turns on, the current is applied twice at the interval of 1 sec as shown in Fig.2-1.
- When the operation stops, the position of the valve before the stop is held.




Fig. 2-1




Fig. 2-2

- Before checking the application of current to the reversing valve (4-way valve), disconnect the connector (CN2) and measure the resistance of both ends of the connector, to see if it is $[2500\Omega \pm 10\%]$. Only when the resistance is normal, check the application of current using the following procedures. If the resistance is abnormal, it is caused by either: breakage of a lead wire, or failure of the reversing valve (4-way valve).
- The voltage, when measured by a tester during the application of current to the reversing valve (4-way valve) (when the voltage is measured)

※Switches the indoor unit to "Ion mist and air cleaning operation", and keep pressing the "Test switch" of the outdoor unit electrical part from 1 sec to below 5 sec (while the self-diagnosis lamp LD301 is ON). Afterwards, when the "Test switch" is released, the application of current starts after 1 sec elapses. (Forced cooling operation).

Operating mode		Cooling operation (including forced cooling operation)	(Reference) Heating operation
Tester and CN2 terminal connection point		⊕ terminal of tester to CN2 pin ④ ⊖ terminal of tester to CN2 pin ①	⊕ terminal of tester to CN2 pin ① ⊖ terminal of tester to CN2 pin ④
Types of testers	Analog tester	The tester indicates about 80 VDC and returns to 0V, and indicates about 80VDC again.	The tester indicates about 160 VDC and returns to 0V, and indicates about 160VDC again.
	Digital tester	The tester indicates about a larger value for an instant and returns to 0V, and indicates about a larger value again.	The tester indicates about a larger value for an instant and returns to 0V, and indicates about a larger value again.

※In each operating mode, if the tester is reverse-connected to the CN2 terminal, the tester indicates a value on the -ve (negative) side.

- At the voltage measurement timing, when the voltage is measured with a tester, if the tester indicates the values as shown in the table above, the circuit is functioning normally. (Each tester indicates values differently. Since it is often difficult to read the values of a digital tester, it is recommended to measure voltage with an analog tester).
- ※Since the current is applied only twice in 1 sec, if the timing is missed, correct operations cannot be measured.
- ※If the main body of the reversing valve (4-way valve) is functioning normally, it clicks twice synchronously with the voltage measurement timing.
- If the sound is heard, the reversing valve (4-way valve) is functioning normally.
- ※If the checking of the application of current becomes abnormal, it is a failure of an electrical part.

8. Base Heater Circuit




Fig 8-1

- When the outdoor temperature is lower than a certain temperature, the base heater begins to work and the defrosting ability is enhanced.
- When the outdoor temperature is higher than a certain temperature ($7\pm 3^{\circ}\text{C}$), the protector will work and the power supply of base heater will be cut off.
- When the base heater exceeds 119°C , the temp. fuse will act and cut off the power supply.

SERVICE CALL Q & A

COOLING MODE

Q1 The compressor has stopped suddenly during cooling operation.



A1 Check if indoor heat exchanger is frosted. Wait for 3-4 minutes until it is defrosted.

If the air conditioner operates in cooling mode when it is cold, the evaporator may get frosted.

DEHUMIDIFYING MODE

Q1 Sound of running water is heard from indoor unit during dehumidifying.



A1 Normal sound when refrigerant flows in pipe.

Q2 Cold air comes out during a dehumidifying operation.



A2 To improve the dehumidification efficiency performs quiet fan operation. Therefore the air is cold and it is not a malfunction.

Q3 The operation does not stop even by setting the temperature higher than room temperature on the remote controller.



A3 It sets to perform dehumidifying operation by setting the temperature slightly lower than remote controller setting.

AT STARTING OPERATION

Q1 When only the circuit breaker is turned ON, the deflector at the air outlet move even if the cooling button is not pressed.



A1 To ensure correct opening and closing of the deflector, they will move when power is turned on or the unit is to be operated in order to check its fully opened and closed positions.

OTHERS

Q1 Loud noise from the outdoor unit is heard when operation is started.



A1 When operation is started, the compressor rotation speed goes to maximum to increase the cooling capability, so noise becomes slightly louder. This does not indicate a fault.

Q2 Noise from the outdoor unit occasionally changes.



A2 The compressor rotation speed changes according to the difference between the thermostat set temperature and room temperature. This does not indicate a fault.

Q3 There is a difference between the set temperature and room temperature.



A3 There may be a difference between the set temperature and room temperature because of construction of room, air current etc. Set the temperature at a comfortable level for the space.

Procedure for Disassemble and Reassemble

1. Front Panel

- (1) Pull up the washable panel by holding it at both lower sides with both hands.



Fig. 1

- (2) When the panel opens full, pull the inner part of the right arm outward and pull the panel forward while closing it gradually.




Fig. 2

2. Front Cover

- (1) After removing one screw and electrical cover, disconnect the UV Led connector from the wire connection.




Fig. 3

- (2) After removing two caps and two screws, open the louver a bit. Then, pull the center of the front cover forward and release the claws.
- (3) Hold the front cover at both lower sides and pull them forward to remove.




Fig. 4

3. Main P.W.B and Reception/Indication P.W.B

- (1) Remove each connector from the lead wire.
- (2) Remove the two P.W.B supports from the main P.W.B.
- (3) After removing the reception/indication P.W.B cover, pull the support hook at the right side of the reception/indication P.W.B and pull out the P.W.B forward.




Fig. 5

4. Tangential air flow fan and fan motor

- (1) Press to the hook down at the center of the unit a little and pull the claw forward to remove the drain pan.




Fig. 6

- (2) Remove the screws from the bearing cover.
- (3) Remove the locking hook of the bearing cover from the Cabinet.






Fig. 7

- (4) Remove the two lock screws from the fan motor holder and one screw from the evaporator support plate.
- (5) Pull up the evaporator by holding it at the lower side. Insert a screwdriver through the space between the evaporator and fan motor holder and loosen the fan lock screws to remove the air flow fan and fan motor.




STRUCTURE OF AN INDOOR UNIT ELECTRIC PARTS



Removing electrical parts

1. Remove the electrical parts cover.
2. Remove the connectors from the CN4 (heat exchange thermistor), CN9 (Vertical sweep motor) and CN2 (fan motor), **CN12** (horizontal sweep motor).
3. Remove four lock screws.



Removing control P.W.B.

1. Pull off all the wires from terminal 1,2,3 or remove the terminal [1,2,3] from the chassis.
2. Remove the P.W.B from the P.W.B support.

Remove the indicating P.W.B.

1. Remove the connector from the CN16A on the control P.W.B.
2. Remove the upper hook from the indicating P.W.B. lock resin, pull the P.W.B. forward a little and remove it.

Procedure for Disassembly and Reassembly

OUTDOOR UNIT

MODEL RAC-SH09WHLAE, RAC-SH12WHLAE

1. Electrical Parts

- (1) Remove the top cover fixing screws and lift the cover to remove it.
- (2) Remove the handle cover fixing screws and push it down to take it out.




Fig. 9

- (3) Remove the electrical box fixing screws.





Fig. 10

2. Dismantle procedure of MAIN PWB.

- (1) Remove terminal cover.



- (2) Remove the terminal block screw, inductance line, line clip, GRN wire, LN123 wire.




Fig. 11

- (3) Set the electrical box upside down.




Fig. 12

- (4) Remove each connector and earth cable from the lead wire. Then, remove the electrical box.




Fig. 13

3. The PWB.

- (1) Remove the electrical cover.




Fig. 14

- (2) Remove the PWB from the support.




Fig. 15



TROUBLE SHOOTING

Inspection instructions




Warning

Note that the 0V line of the outdoor electrical parts and the primary power circuit of the indoor electrical parts have voltages to ground as illustrated in the right-hand figure.



Warning

When conducting a check with an oscilloscope or something similar, do not ground the oscilloscope. Note that the oscilloscope will be subjected to voltages as illustrated in the figure above.



No	Function	Description
1	Self-diagnosis display [Display on the indoor unit side]	<ul style="list-style-type: none"> The failure mode detected on the indoor unit side is displayed by blinking the "timer lamp". And a failure detected on the outdoor unit side will be indicated by the "timer lamp" blinking 4 times. If the outdoor unit side detects a failure, the product will first conduct several operation retrials. There are some failure modes with no lamp display while retrials are continued. <p>[Failure mode where retrials are continued and the indoor unit lamp does not end up giving a display]</p> <ul style="list-style-type: none"> OH thermistor heat-up Overload lower limit cut Low-frequency things
	[Display on the outdoor unit side]	<ul style="list-style-type: none"> The failure mode detected on the outdoor unit side is displayed by blinking the "LD301". Detecting a failure will stop the outdoor unit and keep blinking the LD301 until it is restarted. (The communication error will persist until the communication is reestablished.)
2	Self-diagnosis memory	<ul style="list-style-type: none"> The failure modes detected on the indoor and outdoor unit sides are stored in the nonvolatile memory of the indoor unit and can be read later on. (The memory will remain even after power-off.) The failure modes detected on the outdoor unit side are written in memory every time any such mode occurs. The failure mode can therefore be detected on the indoor unit side without waiting for the retry frequency to reach the display of the indoor unit lamp. Moreover, the normal self-diagnosis display function which rarely occurs will store and display failure modes that do not end up displaying the indoor unit lamp. (Any such mode may be unable to be stored if indoor or outdoor communications is in a failure.) The product stores 5 last-stored failure modes. There is a function for deleting memory. Once you clear the memory and run the product for several days, you can read the failure modes and check them, thereby detecting the less frequent failure phenomena. Failure modes can be checked by both the blinking of the lamp of the indoor unit and the display of the remote control liquid crystal display.

※The "self-diagnosis function of the communication circuit" available in our conventional models is now incorporated as part of the normal self-diagnosis function. In the case of a failure in the communication circuit, you do not have to conduct a special operation and the operations can be automatically divided into 3 blinking operations and 12 blinking operations of the timer lamp.

DISCHARGE, PROCEDURE AND POWER SHUT OFF METHOD FOR POWER CIRCUIT



WARNING



Caution





- Voltage of about 325V is charged between the terminal of smoothing capacitor.
- During continuity check for each circuit part of the outdoor unit, be sure to discharge the smoothing capacitors.

Discharge Procedure

1. Turn of the power.
2. After power turned OFF, wait for 10 minutes or more. Then, remove electrical parts cover and apply soldering iron of 30 to 75W for 15 seconds or more to (+) Positive (-) Negative terminals on the Main PWB as shown in the figure below, in order to discharge voltage in smoothing capacitor.

Do not use a soldering iron with transformer; otherwise, thermal fuse inside transformer will be blown.

Open the cover of the electrical part in the direction of the arrow



As shown in the figure above, apply the soldering iron to the “+” and “-” terminals of C021 to discharge the charging voltage of the smoothing capacitor.


Other instructions

(1) Detaching and reattaching the receptacles for tab terminal

All the receptacles for connecting tab terminals are with a locking mechanism. Forcibly pulling any such receptacle without unlocking it will destroy it. Be on guard.


When reconnecting it, insert it securely all the way home.

· Receptacle types and how to unlock them



Vertical (with a resin case)

Hold the resin case and pull it out.




Horizontal (with a mild resin cover)

Hold the cancel button down on the mild resin cover while pulling it out.

(2) Detaching and reattaching the board connector

The product comes equipped with many board connectors provided with lock mechanism. Forcibly pulling any such part without unlocking it will destroy it. Be on guard. When reconnecting it, insert it securely all the way home.

Pinch the locking mechanism with your fingers and pull it out unlocked.




(3) Do not detach or reattach the connectors while energized

Do not under any circumstances detach or reattach the connectors while energized. That would destroy the board components and fan motor. For both the indoor and outdoor boards, ensure that the smoothing capacitor has discharged its electricity fully before you do your work.

SELF-DIAGNOSIS DISPLAY MODE (INDOOR SIDE)










While the "timer lamp" (orange), of the indoor unit is blinking, troubleshoot the product while referring to the table below.

- How to count the lamp blinking frequency
 - The product will repeat blinking with 2-second intermissions.
 - The blinking speed is as follows: on for 0.35 seconds and off for 0.35 seconds.



- If you wish to try another operation while the lamp is blinking, operate the START/STOP button on the remote control unit twice. The first push will reset the indoor microcomputer, while the second will activate the product

Refer to the table below if the timer indicator (orange) is blinking.

LAMP BLINKING MODE	MAIN DEFECTIVE
 ONCE	REFRIGERANT CYCLE DEFECTIVE
 2 TIMES	FORCED OPERATION OF OUTDOOR UNIT
 3 TIMES	INDOOR INTERFACE CIRCUIT
 4 TIMES	OUTDOOR ELECTRICAL ASSEMBLY DEFECT
 9 TIMES	ROOM OR HEAT EXCHANGER THERMISTOR OR HUMIDITY SENSOR DEFECT
 10 TIMES	OVERCURRENT IN DC FAN MOTOR
 12 TIMES	OUTDOOR INTERFACE CIRCUIT
 13 TIMES	IC531 OR EEPROM DATA DEFECT
( - LIGHT FOR 0.35 SEC AT INTERVAL OF 0.35 SEC)	

- * IF THE INTERFACE CIRCUIT IS DEFECTIVE WHEN THE POWER IS TURNED ON. THE SELF-DIAGNOSIS INDICATION WILL NOT WORK.
- * IF THE INDOOR UNIT CAN NOT BE OPERATED AT ALL.

REFER TO THE BELOW TABLE IF THE INDOOR UNIT DOES NOT WORK AT ALL.


FIX CN2 CONNECTOR	ACTION /REPLACEMENT PARTS, etc
FU1 (3.15A) FUSE BLOWN	REPLACE THE PART WHICH CAUSED BLOWING/DISCONNECTION OF FU1(3.15A) FUSE
COME OFF OR DISCONNECTION OF THE CONNECTOR FOR INDICATING P.W.B	FIX CN16 CONNECTOR
FAILURE OF CONTROL P.W.B	REFER TO THE SERVICE GUIDE FOR HOW TO DETERMINE THE FAILED PART

⚠ DANGER (ABOUT DC350V)

CUT THE POWER SOURCE AND WAIT MORE THAN 10 MINUTES BEFORE SERVICING WORK.
MEASURE DC VOLTAGE (※1) AND CONFIRMED THAT IT IS MUST BE LESS THAN 10V.

※1 DC VOLTAGE VALIDATION, LED POSITION AND FAN OPERATION REFER TO THE SERVICE MANUAL.

[WIRING DIAGRAM]



BLU: BLUE RED: RED
BLK: BLACK WHT: WHITE
BRN: BROWN YEL: YELLOW
GRN: GREEN GRY: GRAY

LED (※1) INDICATION DURING COMPRESSOR OPERATION	
LD301	OPERATION STATUS
LIT	NORMAL
BLINK REPEATINGLY WITH 2 SECONDS LIT - 0.3 SECONDS OFF (NORMAL)	OVERLOAD

LED INDICATION DURING STOP

LD301	SELF-DIAGNOSE CONTENT	CHECKING POINT AND REPAIR METHOD
OFF	NO POWER SUPPLY	NO POWER SUPPLY AT TERMINAL "L - N" → CHECK POWER CABLE CONNECTING CABLE MISCONNECTION → CHECK CONNECTING CABLE REACTOR CONNECTOR HALF INSERTION → CHECK REACTOR CONNECTOR F4 (2A FUSE) BLOWN → REPLACE FUSE AND CHECK OUTDOOR FAN MOTOR NOT MALFUNCTION
1 TIME BLINK	RESET STOP	FAN OPERATION※1: WAITING COMPRESSOR TO START → NORMAL OTHER → IF STILL NOT SOLVE AFTER CHECK THE CONNECTION CABLE, CHANGE ODU CONTROLLER
2 TIMES BLINK	PEAK CURRENT CUT	SERVICE VALVE NOT OPEN → CHECK SERVICE VALVE COMPRESSOR CONNECTOR NOT CONNECTED → CHECK CONNECTOR
3 TIMES BLINK	ABNORMAL LOW SPEED ROTATION	OUTDOOR UNIT SURROUNDING IS BLOCKED → REMOVE THE CAUSE OF BLOCKING. THE CYCLE PIPE ABNORMAL → CHECK THE CYCLE PIPE (ODU(※4) CONTROLLER IS ABNORMAL OR COMPRESSOR IS ABNORMAL) (REFER TO THE SERVICE MANUAL [SELF-CHECK])
4 TIMES BLINK	SWITCHING FAILURE	SERVICE VALVE NOT OPEN, REFRIGERANT LEAK → CHECK SERVICE VALVE, RE-CHARGE THE REFRIGERANT
5 TIMES BLINK	OVERLOAD LOWER LIMIT CUT	BAD CONNECTOR INSERTION, CIRCUIT DEFECT → CHECK THE CONNECTOR, CHANGE ODU CONTROLLER
6 TIMES BLINK	COMPRESSOR TEMPERATURE RISE	THERMISTOR CONNECTOR HALF INSERT → INSERT CONNECTOR SECURELY
7 TIMES BLINK	THERMISTOR ABNORMAL	THERMISTOR WIRE SHORTED OR CUT, CIRCUIT DEFECT → CHANGE THERMISTOR, CHANGE ODU CONTROLLER
9 TIMES BLINK	COMMUNICATION ERROR	CABLE MISS CONNECTION, DISCONNECTIN → CHECK THE F CABLE COMMUNICATION CIRCUIT ABNORMAL → CHANGE ODU CONTROLLER
10 TIMES BLINK	POWER SUPPLY VOLTAGE ERROR	AC VOLTAGE ABNORMAL (BEYOND RATED VOLTAGE ±10% → SUPPLY CORRECT VOLTAGE AC VOLTAGE NORMAL (WITHIN RATED VOLTAGE ±10% → CHANGE ODU CONTROLLER
11 TIMES BLINK	FAN STOP BY STRONG WIND	TEMPORARY STOP DUE TO STRONG WIND → FAN WILL RE-START AFTER WIND BECOME WEAK
12 TIMES BLINK	FAN LOCK STOP	TEMPORARY STOP DUE TO STRONG WIND → FAN WILL RE-START MOVING LATER SOMETHING BLOCKED SURROUND OUTDOOR UNIT → REMOVE THE OBSTRUCTION CONDUCT OUTDOOR FAN MOTOR CHECK → REPLACE THE DEFECT PART
13 TIMES BLINK	EEPROM READING ERROR	CHANGE ODU CONTROLLER
14 TIMES BLINK	DC VOLTAGE ABNORMAL	CONFIRM AC POWER SUPPLY & DC VOLTAGE IS NORMAL → CHANGE ODU CONTROLLER COMPRESSOR LOAD ABNORMAL → INSPECT THE COMPRESSOR
15 TIMES BLINK	CIRCUIT ABNORMAL	CHANGE ODU CONTROLLER (SOME MODELS HAVE NOT 15 TIMES BLINK)
16 TIMES BLINK	HIGH LOAD DURING STOP	SERVICE VALVE NOT OPEN → CHECK SERVICE VALVE SOMETHING BLOCKED SURROUND OUTDOOR UNIT → REMOVE THE CAUSE OF BLOCKING DUST ON INDOOR UNIT FILTER → CLEAN UP THE FILTER

[OUTDOOR FAN MOTOR CHECK] DIAGNOSIS METHOD		OTHERS CHECKING POINT
1. SWITCH OFF MAIN POWER SUPPLY.		1. [REVERSING VALVE NOT OPERATE ERROR] → UN-INSERT THE CONNECTOR AND CHECK CHECK THE LEAD WIRE.
2. UN-INSERT OUTDOOR FAN MOTOR CONNECTOR CN24.		→ IF OK CHECK F3 (2A) FUSE. IF BROKEN REPLACE THE FUSE OR ODU CONTROLLER.
3. MAKE SURE NO ABNORMALITIES AT THE FAN SHAFT.		2. [COMMUNICATION ERROR] OR OUTDOOR UNIT NO OPERATION → CHECK CONNECTING CABLE BETWEEN INDOOR UNIT AND OUTDOOR UNIT.
4. MEASURE RESISTANCE AT FAN MOTOR CONNECTOR CONTACT. NORMAL RESISTANCE BETWEEN EACH TERMINAL REFER TO THE SERVICE MANUAL.		
5. IF NO ABNORMAL AND FAN MOTOR NORMAL. CHANGE ODU CONTROLLER.		

※3 F1 CURRENT VALUE BE DIFFERENT FOR DIFFERENT MODELS.

※4 ODU = OUTDOOR UNIT.

CHECKING THE REFRIGERATING CYCLE

(JUDGING BETWEEN GAS LEAKAGE AND COMPRESSOR DEFECTIVE)

1. Troubleshooting procedure (No operation, No cooling)

Connect U,V,W phase leads to the power module again and operate the air conditioner.



Is the self-diagnosis lamp mode as shown on the right?

Lighting mode Self-diagnosis lamp	Blinks 2 times	Blinks 3 times	Blinks 4 times	Blinks 5 times	Blinks 6 times
LD301					
Time until the lamp lights	Approx. 10 seconds			Approx. 10 seconds	Within Approx. 30 minutes
Possible malfunctioning part	Compressor				Gas leakage


Blinking off

YES



Stop to operate and check the gas pressure in balancing mode.

Normal



● Checking the IPM (main P.W.B.)

Error (Gas leaking)




Gas leaks.
Repair and seal refrigerant.

When the self-diagnosis lamp lights in the same condition as above.



The compressor is defective. Replace it and seal refrigerant.
(If the compressor checker for an inverter type air conditioner is available, re-check using it.)












Perform a final check of operation.



Self Diagnosis Memory Function

Failure mode are stored in the non-volatile memory of indoor unit and can be redisplay by operating the remote controller. This function is very useful in checking the failure modes when either unintentionally switching OFF power supply or restarting the unit operation without conforming the number of blinking of self diagnosis lamp. Remote controller can be redisplay up to last 5 failure modes from the memory. However, failure modes which are rarely occur are also stored in the memory which caused the number of failure easily become more than 5. Thus, for some failure modes which are unable to retrieve because of the remote controller limit to redisplay only 5 failure modes, it can be found by clearing up the memory first then recheck the memory content again during the visit at the customer place.






<How to redisplay failure diagnosis>

1. Turn OFF the circuit breaker on the unit side. (wait for around 5 second)
2. Press the [ (MODE)] button and select [Cool mode ()]. The remote should be in 'Standby' mode.
3. Turn the circuit breaker ON.
4. Set the room temperature on the remote controller to 32°C by pressing the [ (Temp Up)] button.
5. Set which failure information that need to be redisplay by using [ (Fan Speed)] button.
(Refer to the corresponding table below)

Fan Speed		Failure data stored
Auto		Latest
Hi		2nd latest
Med		3rd latest
Lo		4th latest
Silent		Oldest

6. While directing the remote controller towards the receiver of the indoor unit, press [ (Temp Up)] button and [ (On/Off)] button simultaneously.
(The remote controller perform signal transmission with the indoor unit)
7. The indoor unit beep [Pi-] to indicate that it has just received the signal to redisplay the failure mode.
8. Start counting the number of blinking of the Timer lamp (indicating indoor error) and Operation lamp (indicating outdoor error) and confirm it with indoor unit or outdoor unit self-diagnosis table.
9. After everything is completed, turn OFF the circuit breaker (must do without fail).










<How to clear the stored data>


1. Conduct the redisplay of failure mode. (Follow above procedure)
2. Turn the circuit breaker OFF. (Wait for 5sec or more)
3. Press the [ (MODE)] button and select [Dry mode ()]. The remote should be in 'Standby' mode.
4. Turn the circuit breaker ON.
5. Set the room temperature on the remote controller to 16°C by pressing the [ (Temp Down)] button.
6. While directing the remote controller towards the receiver of the indoor unit, press [ (Temp Down)] button and [ (On/Off)] button simultaneously.
(The remote controller perform signal transmission with the indoor unit.)
7. The indoor unit beep for a few second [Pi-] to indicate that it has just receive the signal. The data has been cleared.
8. After everything is completed, turn OFF the circuit breaker (must do without fail).








Notes:



- * This function is valid only once right after the power supply is turned ON and it will not work if other remote controller operation was made prior to it.
Also, this function will not work if above steps were not followed accordingly. (If the above procedures are not working, please repeat from the start.)
- * If nothing was stored in the memory, the lamp does not blink even the redisplay operation is carried out.
- * To carry out normal operation, turn OFF the power supply. After redisplay operation, the remote controller reception will not work as normal.

HOW TO CHANGE THE SHIFT VALUE SETTING TEMPERATURE



1. While pressing and holding  (ON/OFF) button and  button, press **RESET**  [RESET] button on the same. Release **RESET**  [RESET] button only and make sure that all marks on the remote controller display are indicated then release the  (ON/OFF) button and  button. Remote controller now enters "Shift Value Change Mode".
2. Press the  (MODE) selector button so that the display indicates  (FAN) mode.
3. Press the  (ON/OFF) button and FAN operation will be started.



4. Set the FAN SPEED with the  (FAN SPEED) button according to the following FAN speed setting in order to choose the desired operation mode that is required for shift value setting temperature modification.
 - To change the shift value for COOLING mode operation, select either  (HIGH) or  (MED) FAN SPEED.
 - To change the shift value for HEATING mode operation, select either  (LOW) or  (SILENT) FANSPEED.
5. Press the (TEMP  or ) button to change the shift value. (The shift value changed with device producing beep sound.)



NOTE :

1. The displayed shift value,  (HEAT) and  (COOL) symbol on the remote controller display will disappear after 10 seconds.
2. The changed shift value will remain unchanged after turned off the power.
3. If "0" is displayed on the remote controller display, it indicates the shift value is now at the initial setting.

SETTING THE PREVENTION OF MUTUAL INTERFERENCE FOR REMOTE CONTROLLER

a.) Other indoor circuit breakers should be disconnected.




b.) Remove the back cover of the remote control.

c.) Cut the jumper as shown below.

d.) Press "Reset" button after installing the battery.

e.) Corresponding to the room electrical box dial code 6 to dial on.



Cut (Attention: Remove the battery before cutting. Do not cut with electricity).





f.) Please use the remote control to check the available models of corresponding indoor machines.


HOW TO CHANGE THE FAN SPEED IN COOLING MODE DURING THERMO OFF

The fan speed in Cooling Mode during thermo off can be changed by the remote controller.
 (This procedure shall be implemented strictly by service personnel only.)
 It is possible to return it to the default setting.

PROCEDURE

Press  [POWERFUL] button and  [ECO] button simultaneously for about 5 seconds when the remote controller is OFF.

Transmission sign lights up with beep from indoor unit simultaneously.



Beep sound pattern :
 1) Default setting : Short beep
 2) Changed setting : Double beep

	Fan speed during thermo off
Default Setting	Ultra low
Changed Setting	Set fan speed (When auto fan speed is set, the fan speed is low)

NOTE :

- (1) The selected fan speed will remain unchanged after the unit is turned off.
- (2) If Timer reservation has been set, it will be canceled.
- (3) During time setting and timer setting, this operation cannot be set.




HOW TO CHANGE THE INTERMITTENT FAN HEATING SETTING


The intermittent fan control during thermo off in Heating mode can be changed by the remote controller.



(The procedure should be done only by service personnel.)

It is possible to select from 3 patterns.


PROCEDURE



Press  (POWERFUL) button,  (FAN SPEED) button and press  [RESET] button simultaneously.

Release  [RESET] button only and make sure that all marks on the remote controller display are indicated, then release


 (POWERFUL) button and  (FAN SPEED) button.

Remote controller now enters "Intermittent Fan Control Change Mode".



Press [ROOM TEMPERATURE setting] [ (UP) /  (DOWN)] button.

(The intermittent pattern changed with indoor unit beep sound)



	Pattern 1	Pattern 2	Pattern 3
Single model	Continuous	30sec ON / 210sec OFF repeatedly	50sec ON / 190sec OFF repeatedly
Multi	30sec ON / 210sec OFF repeatedly	50sec ON / 190sec OFF repeatedly	Continuous









NOTE:


- (1) The indication of the selected intermittent pattern will disappear after 10 seconds.
- (2) The selected intermittent pattern will remain unchanged after the unit is truned off.



DISPLAY OPERATION MODE SETTING


For operating indoor unit independently (without outdoor unit connection), remote controller must be set according to below procedures before send the signal to the indoor unit. New communication format between indoor and outdoor is required to communicate with outdoor unit.

PROCEDURE

1. While pressing and holding  (ON/OFF) button and , press  (RESET) button on the same time. Release  (RESET) button only and make sure that all marks on the LCD display are indicated, then release the  (ON/OFF) button and  (UP/DOWN) button. Remote controller now enters "DISPLAY OPERATION MODE" for the indoor unit to run independently. Please ensure that when pressing  (FAN SPEED) button, "" will be blinking.




2. Press the  (MODE) selector button to choose the desired operation mode.
3. Press  (ON/OFF) button.
Then, the indoor unit will start to operate independently according to the selected operation mode.



NOTE :

- (1) During "DISPLAY OPERATION MODE", "" blinks on LCD of remote controller.
- (2) When operation stops, "DISPLAY OPERATION MODE" is canceled.

Initiating troubleshooting




Checking the indoor unit electrical parts

Introduction

First check the failure phenomenon and status, and then move on to elaborate diagnosis.

Initiating troubleshooting



Turn off the power, wait at least 5 seconds, turn it back on, and observe the way the horizontal vanes move for about 30 seconds.
Check 1: Have the horizontal vanes moved? (Yes/No)

Set the remote control unit to cooling mode, temperature setting 16 °C and operate the product.
Check 2: Has the product received the remote control signal and has the "operation lamp" gone on? (Yes/No)
 If you responded "Yes" to Check 2:
Check 3: Is the compressor of the outdoor unit running? (Yes/No)
 If you responded "No" to Check 2:
Check 4: Does the "Temporary operation switch" work? (Yes/No)

Check results and next check items

Check 1	Check 2	Check 3	Check 4	Next check item
No	No	—	No	Go to "The power does not turn on".
Yes	No	—	Yes	Go to "The unit does not receive signals from the remote controller".
Yes	Yes	No	—	Go to outdoor side to check failure. Please refer diagnosis table for further checking if outdoor show fault.

1. Failure phenomenon: The power will not become turned on.

[Situation] Neither initialization, remote control, nor any other step works on the vane position at power-on.


<p>[Estimated failure locations]</p> <ul style="list-style-type: none"> · 3.15 A fuse blown out · Control power circuit · Connector loose, wire break 	<p>Estimated cause of fuse blowout</p> <ul style="list-style-type: none"> · Abnormally high voltage applied to the power supply · Indoor fan motor out of order · Power circuit out of order
--	---

[Cautions]

- Before work, check the power supply voltage. An abnormal voltage may be being supplied in some rare occasions due to a defect in the indoor wiring (a wire break in the neutral wire of the single-phase 3-wire power supply).
- If the 3.15 A fuse has blown out, eliminate the cause of the fuse blowout. Otherwise, there will occur another fuse blowout.
- If the 3.15 A fuse has blown out due to an abnormally high voltage to the power supply, the varistor (VA001) will deteriorate and become destroyed as well.
- On a repair service visit due to the failure phenomenon of "The power will not become turned on", take a "3.15 A fuse" and a "varistor" with you.

[Diagnosis flow]

Initiating troubleshooting




2.Failure phenomenon: The product will not receive a remote control signal.

- [Situation] The product does not receive a remote control signal. It is not very responsive.
(The product does run normally in response to the emergency operation switch.)
- [Estimated failure locations]
- Remote control failure, remote control low battery level, remote control poorly set
 - Remote control light-receiving unit
 - Connector loose, wire break
 - Normal product (external factors: the remote control units for lighting equipment and other equipment, electrical noise, etc.)
- [Cautions]
- Even if the product is trouble-free, a factor coming from outside the product may hamper the reception of signals from the remote control unit.
 - Batteries may decline in capacity at low temperatures. Old batteries decline particularly much in voltage in the morning and evening of winter, resulting in the poor arrival of remote control signals. Instruct your users to use new alkaline batteries.

[Diagnosis flow]

Initiating troubleshooting



[Cautions in replacing the indicating P.W.B] Be sure to replace the indicating P.W.B. components.

How to identify sources of jamming in the reception of remote control signals

[Situation] The product may become poorly responsive to remote control signals due to external factors even though the product itself is trouble-free.



[Estimating sources of jamming] Identify the installation status of the air-conditioner and the indoor and outdoor environments to identify possible causes of the jamming.


- Indoor lighting equipment (quantity, type, location)
- Remote control units of other electrical products and equipment
- Is the grounding for the air-conditioner shared with other equipment?
- Are the surroundings of the air-conditioner clear of wireless antenna?
- Is the remote control light-receiving unit protected from direct sunlight?

[Checking and actions]

<p>Effects of lighting equipment (fluorescent lamps)</p>	<p><u>Checking points</u></p> <ul style="list-style-type: none"> · Turn on and off the lighting equipment and check for its effects on the reception of remote control signals. · When cold, the fluorescent lamp tends to emit infrared rays with wavelengths close to those used in remote control. If you cannot detect the phenomenon about which your user is complaining at the time of your visit, such as "the product sometimes fails to receive remote control signals" and "the product fails to receive remote control signals in the morning alone", then turn off the lighting for about 20-30 minutes and wait for the fluorescent lamps to cool down before conducting another check. There are even cases where the product fails to receive remote control signals for 1 to 2 minutes only after the lighting equipment is turned on. · The noise status may vary with the dimming of the lighting equipment. In the case of lighting equipment with a dimmer, therefore, conduct a check with all the light intensities. · If the lighting equipment is the source of the jamming, the remote control light-receiving unit output usually shows a noise waveform as shown in the right-hand figure. In the case of slight jamming, this kind of waveform will not cause practical problems. However, intense degrees of jamming will disable the reception of remote control signals. · When the fluorescent lamp is old and is flickering, it may cause disorders in the reception of remote control signals. <p><u>Actions proposed</u></p> <ol style="list-style-type: none"> 1. Make it hard for light of the lighting equipment to enter the remote control light-receiving unit. <ul style="list-style-type: none"> · Separate the lighting equipment from the indoor unit. · Raise the lighting equipment. · Cover the upper half of the light-receiving panel from its rear side with aluminum tape or black vinyl tape. <p>(This will also affect the reception of remote control signals. Therefore, set the range to be covered with tape to a range that is problem-free in practice, while checking the reception status.)</p> 2. Add an interference filter to the front panel of the remote control light-receiving unit. <ul style="list-style-type: none"> ※ Lighting equipment that produces strong jamming exists although rarely. Some problems may therefore be unsolvable by managing the air-conditioner side alone.
<p>Effects of the remote control units of other equipment</p>	<p><u>Checking points</u></p> <ul style="list-style-type: none"> · If, on the remote control unit of a TV or audio equipment, its sound volume key or something similar is left pressed, infrared signals become continuously sent, thereby jamming the reception of remote control signals. · Check how the remote control unit and related components are stored, thereby checking if there is any possibility that a button may be inadvertently left pressed on the remote control unit of other equipment. <p><u>Actions proposed</u></p> <p>If there is any such possibility, give explanations to your users to that effect and instruct them to exercise caution.</p>

Output waveform of the remote control light-receiving unit





Effects of other electrical products	<p><u>Checking points</u></p> <ul style="list-style-type: none"> · Check the effects of light and power noises coming from other electrical products. · Turn on and off the electrical products, turn off the power and turn on the power, and check their effects on the reception of remote control signals. · For products whose operating states change, check the effects of each state. <p><u>Actions proposed</u></p> <ul style="list-style-type: none"> · Change the location relationship between the air-conditioner and the target products. · Use a different wall outlet for the target products.
Sharing a grounding	<p><u>Checking points</u></p> <ul style="list-style-type: none"> · Check for effects of electrical noises coming into the air-conditioner through grounding wires. · Check if the grounding works is for the air-conditioner alone or shared with other equipment. If there is any equipment that shares it, turn on and off that equipment and detach and reattach the power plugs and examine their effects on the reception of remote control signals. <p><u>Actions proposed</u></p> <ul style="list-style-type: none"> · Establish an independent grounding for the air-conditioner.  <p>The diagram illustrates a house with a roof and a chimney. Inside, an 'Air-conditioner' is connected to a power outlet on the left wall. On the right wall, 'Other equipment' is also connected to a power outlet. Both power outlets are connected to a single 'Grounding' point at the bottom center of the house, represented by a vertical line with three horizontal bars at its base.</p>
Effects of radio waves	<p><u>Checking points</u></p> <ul style="list-style-type: none"> · Using a wireless transmitter near the air-conditioner may affect the reception of remote control signals. · Have your users try sending signals with a wireless transmitter and examine their effects on the reception of remote control signals. <p><u>Actions proposed</u></p> <ul style="list-style-type: none"> · Add a ferrite core to the power cord and F cable. · Add a ferrite core to the internal wiring of the indoor unit. · Move the wireless antenna.
Effects of direct sunlight	<p><u>Checking points</u></p> <ul style="list-style-type: none"> · Direct sunlight and other intense light make the remote control light-receiving unit less sensitive. · Check for any time zone where the remote control light-receiving unit of the indoor unit is affected by direct sunlight depending on the location of the sun and mirror reflection. <p><u>Actions proposed</u></p> <ul style="list-style-type: none"> · Block the sunlight to protect against direct sunlight.

3. Failure phenomenon: The compressor will not run.

[Situation] The compressor will not run (the same state as the thermometer turned off), the product receives remote control signals normally. The self-diagnosis lamp (LD301) of the outdoor unit blinks once or becomes turned off.

[Estimated failure locations] · Room temperature thermistor, heat exchanger thermistor
· Microcomputer peripheral circuit

[Diagnosis flow]
Initiating troubleshooting




4. Failure phenomenon: The fan motor will not stop.

[Estimated failure locations]

- Indoor fan motor
- Fan motor drive circuit

[Diagnosis flow]

Initiating troubleshooting



5. Timer lamp blinking: blinking once

[Situation] The timer lamp blinks one time and the product will not operate.
(This is not a sign of a breakdown.)

[Estimated failure locations] · Reversing valve defective.
· The refrigerating cycle block gas leak.

6. Timer lamp blinking: blinking twice

[Situation] The product is giving a display to indicate that it is performing forcible cooling.
(This is not a sign of a breakdown.)

7. Timer lamp blinking: blinking three times

[Situation] The timer lamp blinks three times and the product will not operate.

[Estimated failure locations] · Meltdown of the terminal board (the terminal board poorly inserted into the connecting cable)
· Outdoor communication circuit out of order

[Cautions] · If a terminal board is replaced to counter the meltdown of the terminal board, ensure that the connecting cable to be inserted into the terminal board has the appropriate dimension for peeling the insulation sheathing and that the insertion region is unbent before inserting it into the terminal board securely.

8. Timer lamp blinking: blinking four times

[Situation] The timer lamp blinks four times and the product will not operate.

[Estimated failure locations] · Outdoor unit error.
· Please confirm the times of the LD301 blinking, and then see the outdoor selfcheck table.

9. Timer lamp blinking: blinking 9 times


[Situation] The timer lamp blinks 9 times and the product will not run.

[Estimated failure location] · Loose connector, wire break, or short-circuit in the room temperature thermistor or heat exchanger thermistor.

[Cautions] · Starting the product by remote control will initiate failure detection.
(Merely turning on the power will not activate the failure detection function.)

[Diagnosis flow]

Initiating troubleshooting




10. Timer lamp blinking: blinking 10 times

[Situation] The timer lamp blinks 10 times and the product will not run.

- [Estimated failure locations]
- Loose connector or wire break in the indoor fan motor
 - Indoor fan motor mechanically locked
 - Indoor fan motor
 - Indoor fan motor drive circuit

[Diagnosis flow]

Initiating troubleshooting



11. Timer lamp blinking :blinking 12 times

[Situation] The timer blinks 12 times and the product will not run.

[Estimated failure locations]

- Erroneous connection in the indoor-outdoor connection line (connecting cable)
- Wire break or poor insertion of the indoor-outdoor connection line (connecting cable)
- Electrical parts in the outdoor unit (communication circuit, power circuit error)
- Communication error due to noise in other home electronics


※This does not constitute a failure in the air-conditioner

[Cautions]

- When lines 1 and 2 of connecting cable are erroneously connected (crossed), the product may not enter self-diagnosis display mode. If the self-diagnosis memory stores data about "timer lamp blinked 12 times", then, just in case, check if the connecting cable is not erroneously connected

[Diagnosis flow]

Initiating troubleshooting



12. Timer lamp blinking :blinking 13 times


[Situation] The timer lamp blinks 13 times and the product will not run.


[Estimated failure location] • EEPROM, microcomputer


[Diagnosis flow]


Replace the "indoor control P.W.B".

Checking the electrical parts of outdoor unit











CHECKING THE REMOTE CONTROLLER




You can check the remote control switch by other methods as explained below.

[Checking with the remote controller check card]



When you operate the remote controller, if the light receiving section reflects in orange, it is normal.

[Checking with Digital camera or phone camera]



- (1) Set the mobile phone so that the transmission part of the remote controller is reflected on the camera's monitor screen.
- (2) When you operate the remote controller, if the transmission part emits light on the monitor screen, it is normal.

Check functions again.
If it does not work, replace the remote controller.

How to run the product with the outdoor unit test switch

If the indoor electrical parts is out of order and if you wish to run the outdoor unit.


1. Turn OFF main power supply.
2. Unplug the CN18 and CN3 connector.
3. Connect the Test Switch jig connector to CN18.
4. Turn ON the outdoor terminal board L and N (230V AC).
5. Confirm that the "LD301" blinks once from the terminal side of the outdoor unit. Afterwards (when about 30 sec elapses after the power turns ON), confirm that the "LD301" changes to blinking 9 times (communication error).
6. When the "LD301" is blink 9 times, if you press the Test Switch, the "LD301" lights up.

If you release your finger from the test switch within 1 sec to 4 sec after pressing the switch, the forced cooling operation starts.

※ (If you press the test switch for 5 sec or longer, the self-check diagnosis starts. In this case, turn the power off and start the procedure from 1 again.)

※ (For the initialization of the expansion valve, it may take 1 min until the operation starts).

7. When you press the Test Switch again for 1 sec or longer, the unit stops the operation.
8. After test run, remove the Test Switch jig connector and be sure to reconnect connector (CN18 and CN3) that you removed earlier. If you forget to connect, the heater does not work properly.



Self-check


If you cannot judge if it is an abnormality on the electrical part or the compressor by the “Blinking twice, 3 times, 4 times or 5 times” of the self-diagnosis indicator, perform the megger check to check the isolation of the compressor has no problems, perform the following [self-check].
(The inverter should be checked).

How to make the self-check diagnosis

1. Turn the power OFF and wait for 10 min or longer.
2. Disconnect communication wire indoor outdoor (Terminal pin no. 3).
3. Insert external service switch at CN18.
4. Turn ON power supply (wait until LD301 9 times blinking).
5. Press service switch 5 sec or longer until LD301 blink fast and then release the switch.
6. Self-check result will display by LD301 blinking times.

While the test switch has been pressed, the LD301 lights up and, if it is pressed for 5 sec or longer, the LD301 repeats a cycle of “Lighting for 0.2 sec and lights-out for 0.2 sec”.
When blinking starts, remove your finger from the test switch.

If you release your finger from the switch below 5 sec, the forced cooling operation starts.




7. The result of self-check diagnosis are indicated. The contents of the result of diagnosis are shown in the table below.
8. The self-check complete.

Result of the self-check diagnosis

SELF-CHECK DIAGNOSIS RESULTS		
LD301	Self-diagnosis description	Solution
Blink 1 time	No problem with electrical parts.	Replace compressor.
Blink 2 times	Peak current cut signal.	Replace electrical parts.
Blink 7 times	Motor current error.	Compressor connector become disconnected. ⇒ Adjust connector. Compressor connector properly connected. ⇒ Check compressor, then replace electrical parts.
Blink 10 times	DC voltage error.	Abnormal AC input power supply (outside range of rated voltage $\pm 10\%$). ⇒ Connect to proper power supply. Normal AC input power supply (inside range of rated voltage $\pm 10\%$). ⇒ Replace electrical parts.
Blink 13 times	EEPROM read error.	Replace electrical parts.

Location of the test switch and LD301



If the judgement results show abnormality, check the connecting wire and, if it is not disconnected, replace the failed parts according to the correcting method.

Cautions

1. The self-check is effective only when the power is turned on for the first time. If the LD301 does not lights up, even if the test switch is pressed, turn the power off and wait for 10 min and start the procedure from the beginning.
2. After the self-check mode is complete, it is not necessary to turn the power off (normal operation is restored). However, note that the self-check results continue blinking until the compressor starts operating.

※Cautions


1. Before making the connections, be sure to turn off the breaker.
2. Do not under any circumstances run the product for more than 5 minutes.
3. Doing work with the compressor connector removed will cause the LD301 to blink 4 times. It will not start.
4. For another test run, turn off the breaker and turn it back on. (The test switch is accepted only once after power-on. After operation by remote control, it is not accepted.)
5. When the operation with the test switch is over, turn off the breaker.

HOW TO OPERATE THE OUTDOOR UNIT INDEPENDENTLY

1. Connect the large dia. pipe side and small dia. pipe side service valve using a pipe.

Connect the small diameter service valve and the large diameter service valve using the reducing union and copper pipe as shown on the right.

Charge refrigerant of 300g after vacuuming (※1)



Parts to be prepared

- (1) Reducing union
2/8" (6.35 mm)
3/8" (9.52 mm)
- (2) Copper pipe (2/8" and 3/8")

Do not operate for more than 5 minutes


The operation method is the same as "How to operate using the connector to servicing the outdoor unit".

※1 The charging amount of 300g is equivalent to the load in normal operation.

PARTS LIST AND DIAGRAM

INDOOR UNIT

MODEL : RAS-SH07QHLAE
RAS-SH09RHLAE
RAS-SH12RHLAE




MODEL RAS-S 0 LAE RAS-S 0 R LAE RAS-S 1 R LAE

NO.	PART NO.	Q'TY / UNIT	PARTS NAME
1	PMRAS-S18CPA R02	1	AUTO SWEEP MOTOR
2	PMRAK-50PPD R03	1	TANGENTIAL FLOW FAN
3	PMRAK-50PPD R0S	1	FILTER
4	PMRAK-50PPD R07	1	TERMINAL BOARD (3P)
5	PMRAS-25YH4 S15	1	SPRING
6	PMRAS-25YH4 908	1	P-BEARING ASSY
7	PMS-SH09RHLAE R02	1	PWB RECEIVER
8	PMS-SH09RHLAE R08	1	FAN MOTOR
9	PMS-SH09RHLAE R04	1	FRONT COVER ASSY
10	PMS-SH09RHLAE R05	1	REMOTE CONTROL ASSEMBLY
11	PMS-SH09RHLAE R03	1	CYCLE ASSY
12	PMRAS-DX24CFT R03	1	FRONT PANEL
13	PMS-EH07QHLAE R01	1	P.W.B (MAIN) (RAS-SH07QHLAE)
13	PMS-SH09RHLAE R01	1	P.W.B (MAIN) (RAS-SH09RHLAE)
13	PMS-SH12RHLAE R01	1	P.W.B (MAIN) RAS-SH12RHLAE)
14	PMRAS-S18CPA R02	1	AUTO SWEEP MOTOR
15	PMRAS-E60YCAB R0S	1	CABINET
16	PMRAS-S18CPA R04	1	CAP
17	PMS-SH09RHLAE R06	1	DRAIN PAN ASSY
18	PMRAS-S18CPA R07	1	BEARING COVER
19	PMRAS-S18CPA R09	1	FAN MOTOR BASE
20	PMRAS-S18CPA R13	1	MOUNTING PLATE
21	PMRAS-S18CPA R15	1	PIPE SUPPORT
22	PMRAS-XH10CKT R06	1	THERMISTOR ASSEMBLY
23	PMRAS-VX13CET R10	1	REMOCON SUPPORT
24	PMRAS-X18CGT R04	1	H-DEFLECT

PARTS LIST AND DIAGRAM

OUTDOOR UNIT

MODEL : RAC-SH09WHLAE
RAC-SH12WHLAE



MODEL RAC- H0 HLAE RAC- H1 HLAE

NO.	PART NO.	Q'TY / UNIT	PARTS NAME
1	PMRAM-33NP2E S04	1	CABINET
2	PMRAC-XH18CKT S02	1	FAN MOTOR
3	PMC-EH09WHLAB S01	1	COMPRESSOR
4	PMC-SH09WHLAE S02	1	CONDENSER
5	PMRAC-VX10CJ S04	1	D-GRILL
6	PMC-EH09WHLAB S13	1	OVERLOAD RELAY COVER
7	PMC-SH09WHLAE S01	1	PWB MAIN
7	PMC-SH12WHLAE S01	1	PWB MAIN
8	PMRAC-X10CZ S05	1	PROPELLER FAN
9	KPNT1 001	3	PUSH NUT
10	PMRAM-33NP2E S05	1	REACTOR
11	PMC-SH09WHLAE S06	1	SIDE PLATE (R)
12	PMC-SH09WHLAE S05	1	STRAINER (COND)
13	PMRAC-S10CAT S03	1	SUPPORT (FAN MOTOR)
14	PMRAC-80YHA S14	1	THERMISTOR (OH)
15	PMC-EH09WHLAB S03	1	TERMINAL BOARD (5P)
16	PMC-SH09WHLAE S04	1	TOP COVER
17	PMRAC-X13CX 902	1	VALVE 2S
18	PMRAC-X10CZ S17	1	VALVE 3S
19	PMC-SH09WHLAE S03	1	SV COVER
20	PMC-EH09WHLAB S10	1	THERMISTOR (OUTSIDE TEMPERATURE)
21	PMRAC-X10CGT S05	1	EXPANSION VALVE
22	PMRAC-25NPA S02	1	ELECTRICAL EXPANSION COIL
23	PMC-EH09WHLAB S11	1	THERMISTOR (DEFROST)
24	PMC-EH09WHLAE S02	1	MG-COIL-SH

HITACHI

**RAS-SH07QHLAE/(MULTI ONLY)
RAS-SH09RHLAE/RAC-SH09WHLAE
RAS-SH12RHLAE/RAC-SH12WHLAE**

PM NO. 0751E

Printed in Malaysia